


## NetBeacon™ Element Management Software Installation and User's Guide



**Version 3.4.0**

**© 1999-2003 Metrobility Optical Systems, Inc.**  
**All Rights Reserved. Printed in USA.**

This publication is protected by the copyright laws of the United States and other countries, with all rights reserved. No part of this publication may be reproduced, stored in a retrieval system, translated, transcribed, or transmitted, in any form, or by any means, manual, electric, electronic, electromagnetic, mechanical, chemical, optical or otherwise, without prior explicit written permission of Metrobility Optical Systems, Inc.

Lancast, the Lancast logo, and "the twister" are registered trademarks; Metrobility Optical Systems, the Metrobility Optical Systems logo, AutoTwister, MicroChassis, NetBeacon, WebBeacon, "twister" and "redundant twister" are trademarks of Metrobility Optical Systems, Inc. Java, Sun, Sun Microsystems, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. All other trademarks are the property of their respective owners.

"redundant twister" technology is a patent of Metrobility Optical Systems, Inc.

The information contained in this publication is accurate as of its publication date; such information is subject to change without notice. Metrobility Optical Systems, Inc. is not responsible for any inadvertent errors.

# Contents

---

<b>CONTENTS</b>	<b>III</b>
ABOUT THIS GUIDE .....	VII
DOCUMENT CONVENTIONS .....	VII
RELATED DOCUMENTS .....	VII
USING THE MOUSE .....	IX
TECHNICAL SUPPORT .....	IX
<b>CHAPTER 1. GETTING STARTED</b>	<b>1</b>
WHAT IS NETBEACON? .....	1
FEATURES AND BENEFITS.....	2
SYSTEM REQUIREMENTS .....	2
Client/Server Specifications with Database Plugin .....	2
NETBEACON CD CONTENTS .....	3
INSTALLING THE JAVA RUNTIME ENVIRONMENT .....	4
Sun Solaris Installation .....	4
HP-UX Installation .....	5
Red Hat Linux Installation.....	5
Windows Installation .....	6
INSTALLING THE NETBEACON SOFTWARE .....	7
UNIX/Linux Installation.....	7
Windows Installation .....	8
UPGRADING NETBEACON.....	14
VIEWING THE INSTALLATION ERROR LOG.....	15
UNINSTALLING THE NETBEACON SOFTWARE .....	15
UNIX Uninstall .....	15
Windows Uninstall .....	16
WHAT'S NEXT? .....	17
<b>CHAPTER 2. NETBEACON BASICS</b>	<b>19</b>
STARTING NETBEACON FROM WINDOWS.....	19
Opening the NetBeacon Server Application.....	19
Opening the NetBeacon Client Application .....	20
STARTING NETBEACON FROM LINUX.....	20
STARTING NETBEACON FROM SUN SOLARIS AND HP-UX.....	21
HP OpenView Network Node Manager .....	21
EXITING NETBEACON .....	23
Closing the NetBeacon Client Application.....	23
Closing the NetBeacon Server.....	24
CHECKING THE NETBEACON VERSION NUMBER .....	25
LEARNING ABOUT THE NETBEACON WINDOW .....	26
Resizing the Windows and Dialog Boxes.....	26
Activity Indicator.....	27
Trap Alerts.....	27
ToolTips .....	27
Chassis View .....	27
Devices List .....	28
Expanding and Collapsing the Devices List .....	29
Fields and Folders.....	29
Shortcut Keys .....	30

Menu Bar .....	31
File Menu .....	31
Edit Menu .....	31
View Menu .....	32
Device Menu .....	33
Help Menu .....	33
Toolbar .....	34
<b>CHAPTER 3. NETBEACON SETUP</b> .....	<b>35</b>
ADDING A DEVICE THROUGH NETBEACON .....	35
ADDING DEVICES FROM HP OPENVIEW NETWORK NODE MANAGER (NNM) .....	36
SELECTING A DEVICE .....	36
UNMANAGING A DEVICE .....	37
DELETING A DEVICE .....	37
RESETTING A DEVICE .....	38
PINGING A DEVICE .....	39
OPENING A TELNET SESSION .....	39
DOWNLOADING SOFTWARE TO A DEVICE .....	40
CHANGING THE DATE AND TIME .....	42
CUSTOMIZING YOUR DISPLAY .....	43
Resizing the Chassis View .....	43
Showing Remote Access Line Cards .....	43
Showing ToolTips .....	44
Changing the Appearance of your Tables .....	44
Changing the Look & Feel of your Display .....	45
Selecting a Temperature Scale .....	45
Refreshing the NetBeacon Window .....	45
PRINTING NETBEACON REPORTS .....	46
Setting Up Pages .....	46
SETTING USER PREFERENCES .....	46
Saving a User Profile .....	47
Renaming a User Profile .....	47
Creating a New User Profile .....	48
Opening a User Profile .....	48
Deleting a User Profile .....	49
Setting Your Password .....	49
VIEWING NETBEACON LICENSE INFORMATION .....	50
Updating the NetBeacon License .....	50
CONFIGURING THE DATABASE .....	51
Adding a Device for Database Management .....	52
Updating the Database Devices List .....	52
Removing Database Devices .....	53
Logging Data .....	53
Creating Database Archives .....	54
<b>CHAPTER 4. MANAGING THE DEVICES</b> .....	<b>55</b>
DISPLAYING DEVICE INFORMATION .....	55
CONFIGURING A DEVICE .....	56
MONITORING THE CHASSIS .....	58
Displaying Chassis Information .....	59
Displaying Temperature and Power Supply Information .....	60
RECEIVING TRAPS .....	62
Monitoring Traps .....	62
Displaying the Trap Legend .....	63
Filtering Traps .....	64

MANAGING TRAPS .....	65
Displaying the Trap Management Table .....	65
Adding a New Trap Manager .....	65
Reconfiguring a Trap Manager.....	66
Deleting a Trap Manager.....	67
SENDING E-MAIL NOTIFICATIONS.....	68
Configuring E-mail Notifications.....	68
Adding E-mail Notifications for Multiple Devices .....	70
Editing an E-mail Notice .....	70
Sending a Test E-mail Notice .....	71
Deleting an E-mail Notice Recipient.....	71
<b>CHAPTER 5. CONFIGURING MODULES AND PORTS .....</b>	<b>73</b>
DISPLAYING MODULE INFORMATION .....	73
Changing a Module Name and Asset ID .....	76
Displaying Management Module Information.....	78
Displaying a Remote Access Line Card or Access ONU Information .....	79
CONFIGURING A CONVERTER .....	80
Displaying Converter Information.....	81
Assigning a Converter Name.....	81
Applying Link Loss Carry Forward.....	82
Applying Copper Loss Carry Forward .....	83
Configuring the Redundant Interface Line Card .....	83
Dynamic Recovery Mode.....	84
Applying SONAR .....	84
Select A/B Mode .....	85
Configuring the 10/100Mbps Line Card.....	86
Link Loss Carry Forward and Full-Duplex Flow Control .....	86
Backpressure (Half-Duplex Flow Control).....	87
Auto-Recovery .....	87
Managing the Chassis Stacking Line Card.....	88
Port Duplex, and Full and Half Duplex Flow Control.....	89
Displaying Access Line Card Details .....	90
Applying Write-Protection .....	91
CONFIGURING THE PORTS .....	91
Displaying Port Details.....	91
Displaying Management Module Statistics .....	92
Displaying RMON Statistics .....	93
Viewing TDM Information.....	94
Changing the Port Name.....	94
Applying Link Loss Return .....	95
Configuring the 10/100Mbps Ports .....	96
Configuring the R133 Ports .....	97
Configuring the Access Line Card Ports .....	98
Displaying Port Statistics.....	100
Viewing Data History Graphs .....	101
Provisioning Bandwidth .....	102
Configuring the T1/E1 Ports.....	103
Selecting the Line Code and Line Buildout.....	104
Setting BERT 511, Remote Loopback, and Far End Fault.....	104
Configuring the T3/E3 Ports.....	104
Setting the T3 Line Buildout .....	106
<b>APPENDIX A. PERSISTENCE DATA .....</b>	<b>107</b>
THE DATABASE PERSISTENCE FILE .....	107

<b>APPENDIX B. DATABASE ARCHIVES</b>	<b>109</b>
ARCHIVE FILES.....	109
ARCHIVE FILE FORMATS .....	110
LOCATING ARCHIVE FILES .....	110
CHANGING ARCHIVE FILE DEFAULT SETTINGS .....	110
DATABASE ARCHIVE DETAILS .....	111
TableCreate.sql .....	111
COPPERPORTSTATS.....	112
FIBERPORTSTATS .....	112
MODULESTATS.....	113
CHASSISSTATS.....	113
UTC TIME CONVERSION .....	114
Conversion Examples and Hints.....	114
Perl Example .....	114
C Example .....	114
GRAPHING GRANULARITY.....	115
<b>APPENDIX C. DOWNLOAD ERROR MESSAGES</b>	<b>117</b>
<b>APPENDIX D. HP NNM CUSTOMIZATION</b>	<b>119</b>
HP NNM INSTALLATION.....	119
ENABLE METROBILITY CUSTOMIZATION .....	119
DETAILS OF TRAPD.CONF CHANGES .....	120
<b>APPENDIX E. DISCONTINUED PRODUCT SUPPORT</b>	<b>125</b>
MANAGED FIXED PORT CHASSIS.....	125
PERSISTENCE DATA FOR A FIXED PORT CHASSIS .....	126
<b>APPENDIX F. NETBEACON WARRANTY STATEMENT</b>	<b>127</b>
<b>APPENDIX G. PRODUCT SAFETY AND COMPLIANCE STATEMENTS</b>	<b>129</b>

## About this Guide

The **NetBeacon™ Element Management Software Installation and User's Guide** provides network managers and system administrators with information about how to configure and manage any Metrobility chassis-based system and related cards.

The reader of this document should be knowledgeable about network devices, device configuration, network management, and Windows or UNIX environments. The user is assumed to be a network administrator or manager with an understanding of network operations.

## Document Conventions

The following conventions are used in this guide.

<b>Bold</b>	Indicates a menu option that you choose, a command that you type, or a command button that you click.
<i>Italics</i>	Indicates a variable for which you provide a value or the title of a document.
<code>Courier</code>	Indicates a message, directory, or filename.
<u>Underline</u>	Indicates a hyperlink. Hyperlinks provide cross-references to other information that is helpful when performing a task.
SMALL CAPS	Indicates a key on the keyboard that you press. For example: Press the SHIFT key.
<b>Tip</b>	Information that is helpful when performing some activity.
<b>Important</b>	Information that is critical to your understanding of how the product works.

## Related Documents

The following documents are additional resources that provide useful information regarding any Radiance or Lancast® chassis and cards, including installation and configuration guidelines. All Metrobility manuals can be found on our website, [www.metrobility.com](http://www.metrobility.com).

*Intelligent 7500 Chassis ~ Installation and User Guide*  
*Radiance R5000 Central Service Platform ~ Installation and User Guide*  
*Radiance R1000 Premise Service Platform ~ Installation and User Guide*  
*Radiance R400 Premise Service Platform ~ Installation and User Guide*  
*Intelligent MicroChassis 7500 ~ Installation and User Guide*

Provides detailed chassis and power supply installation instructions and specifications, and management card setup information.

*Intelligent 7500 Modules ~ Quick Reference*  
*Intelligent 7500 7133 Modules ~ Quick Start Guide*

Contains installation instructions, specifications, switch settings, and connections, in a fast reference format.

*Radiance 10Mbps Single Interface Line Cards ~ Installation and User Guide*  
*Radiance 100Mbps Single Interface Line Cards ~ Installation and User Guide*

Contains installation instructions, specifications, switch settings, and connections for the 10 and 100Mbps cards, including the feature-rich R133 line cards.

*Intelligent 7500 "redundant twister" ~ Installation & User Guide*  
*Radiance 10Mbps Redundant Interface Line Cards ~ Installation & User Guide*  
*Radiance 100Mbps Redundant Interface Line Cards ~ Installation & User Guide*  
*Radiance 1000Mbps Redundant Interface Line Cards ~ Installation & User Guide*

Provides details on how to install, configure, and operate the 10Mbps, 100Mbps and 1000Mbps redundant interface cards. Also includes technical specifications.

*Intelligent 7500 10/100 AutoTwister ~ Installation & User Guide*  
*Radiance 10/100Mbps Interface Line Cards ~ Installation & User Guide*

Contains information on the installation, configuration, network specifications, and operation of the 10/100Mbps cards.

*Intelligent 7500 "twister" 7131 Optical Extender ~ Installation & User Guide*

Contains details on how to install, configure switch settings, and operate the optical extender module.

*Intelligent 7500 Gigabit "twister" and SONET "twister" ~ Installation & User Guide*  
*Radiance Gigabit Single Interface Line Cards ~ Installation & User Guide*  
*Radiance SONET Single Interface Line Cards ~ Installation & User Guide*

Provides installation and operational guidelines for the 1000Mbps, OC-3/STM-1 and OC-12/STM-4 cards.

*Radiance Access Line Cards ~ Installation & User Guide*

Provides details on how to install, configure, and operate the 100Mbps access line cards. Also includes technical specifications.

*Radiance 10/100Mbps Access Optical Network Unit ~ Installation & User Guide*

Provides details on how to install, configure, operate and monitor the 10/100Mbps access optical network unit. Also includes troubleshooting information and technical specifications.

*Radiance T1/E1 Single Interface Line Cards ~ Installation & User Guide*

Contains information on the installation, configuration, technical specifications, and operation the T1/E1 line cards.



### *Radiance T3/E3 Single Interface Line Cards ~ Installation & User Guide*

Contains information on the installation, configuration, specifications, and operation the T3/E3 line cards.

### *Radiance Chassis Stacking Line Card ~ Installation & User Guide*

Provides information on the installation, operation and management of the 10/100Mbps TX four-port chassis stacking line card. Also includes an example of how to configure a stack of four chassis using the card.

### *Command Line Interface ~ Reference Guide*

Contains a complete list of the console commands to configure and manage any Metrobility chassis, as well as instructions on how to set up the management card.

## **Using the Mouse**

Always use the left mouse button when instructed to “click” a command button or choose a menu option, unless you are instructed to “right-click”. If you have reversed the functions of the left and right buttons, use the alternate button when following these procedures. See your platform documentation for further instructions on using your mouse.

## **Technical Support**

Before contacting Technical Support, please make sure you have the following information:

- NetBeacon software version number
- Java Runtime Environment (JRE) version number
- Version of software on the management card
- Management station hardware specifications (RAM, operating system, and CPU)

Refer to [Checking the NetBeacon Version Number](#).

Notify Metrobility Technical Support via e-mail by contacting **techsupport@metrobility.com** or by calling 1.877.526.2278, from 8 AM to 7 PM (EST). You can also fax Metrobility Optical Systems, Inc. at 1.603.594.2887.



# Chapter 1. Getting Started


---

## What is NetBeacon?

The NetBeacon management software is a Java™ application that helps network administrators configure and manage any Radiance or Lancast device. NetBeacon runs under various Microsoft® Windows® and UNIX platforms. It also can be integrated with and launched from HP OpenView Network Node Manager. This version of NetBeacon has been tested on the following platforms:

- Windows 2000
- Windows NT 4.0
- Windows XP Professional
- HP-UX 11.00
- Sun Solaris 8
- Red Hat Linux 7.3

A Radiance or Lancast device is a chassis with slots for one or more manageable line cards (modules) and a management card. The following illustration shows an example of an Intelligent 7500 chassis with 12 slots containing several cards.



Metrobility media converters translate information that enables differing network segments to be integrated (e.g., from copper to fiber, singlemode to multimode, or Ethernet to Fast Ethernet). Modules are the replaceable cards installed into the chassis by the user.

The management card provides an interface between the system hardware (chassis and cards) and NetBeacon.

Connected through the backplane to the modules in the chassis, the management card reports on the status and configuration of individual boards. The network administrator can view this status information and control the device configuration through NetBeacon. The management card, together with NetBeacon, provides the network administrator with the information necessary to achieve efficient operation.

## Features and Benefits

NetBeacon provides an efficient, user-friendly way to configure and manage all of the devices installed on a single network or on a series of networks. You can use NetBeacon as an alternative to the command line interface typically used to configure and operate network devices. NetBeacon provides an intuitive graphical display of each chassis and its cards, along with real-time status information on their operation. Management and operational tasks include the following:

- [Displaying Device Information](#)
- [Configuring a Device](#)
- [Monitoring the Chassis](#)
- [Pinging a Device](#)
- [Opening a Telnet Session](#)
- [Downloading Software to a Device](#)
- [Configuring the Database](#)
- [Sending E-mail Notifications](#)
- [Displaying Module Information](#)
- [Configuring a Converter](#)
- [Displaying Access Line Card Details](#)

## System Requirements

Your management hardware must meet the following minimum requirements.

Platform	CPU	Memory	Disk Space	JRE
Windows	750 MHz	256 MB	20 MB for NetBeacon; 17 MB for JRE	Sun JRE 1.4.1
Red Hat Linux	750 MHz	256 MB	20 MB for NetBeacon; 40 MB for JRE	Sun JRE 1.4.1
Sun Solaris	200 MHz	64 MB	20 MB for NetBeacon; 41 MB for JRE	Sun JRE 1.4.1
HP-UX 11.00	200 MHz	64 MB	20 MB for NetBeacon; 56 MB for JRE	HP-UX JRE 1.4.1

### *Client/Server Specifications with Database Plugin*

If you are installing the database version of NetBeacon, the server application must be installed on a dedicated workstation with the following minimum system requirements:

Platform	CPU	Memory	Disk Space
Windows or Red Hat Linux	750 MHz	512 MB (server) 256 MB (client)	18 GB (server) 15 GB (client)
Sun Solaris	450 MHz	512 MB	18 GB
HP-UX 11.00 PA-8600	552 MHz	512 MB	18 GB

The NetBeacon client application must be installed on a separate machine with the minimum requirements listed above.

**Important:** When using the database plugin, the client and server applications must be installed on two separate machines.

Each NetBeacon server can register up to ten clients.

**Additional software for Microsoft Windows, Sun Solaris, HP-UX, and Red Hat Linux may include:**

- Adobe Acrobat Reader for online viewing of this guide
- HP OpenView Network Node Manager

## NetBeacon CD Contents

The NetBeacon CD contains the following five folders.

Folder	Contents
NetBeacon	The NetBeacon application files, the Java Runtime Environment, Release Notes. The files are separated into Unix and Windows versions.
Firmware	Latest management card firmware (including boot code), and Release Notes.
Manuals	The documentation for installing and configuring various modules and this guide in Adobe Acrobat format (PDF). Refer to the Utilities folder for the latest version of the Adobe Acrobat Reader.  For a complete list of documents available for reference, see <a href="#">Related Documents</a> .
MIBs	Management Information Base (MIB) for use with other network management software, such as HP OpenView. MIB file load order.
Utilities	The latest version of Adobe Acrobat Reader, along with the HP OpenView Network Node Manager configuration scripts.

## Installing the Java Runtime Environment

Install the Java Runtime Environment (JRE) before installing the NetBeacon software. If you have the JRE 1.4.1 software installed already, you may skip this procedure and go to [Installing the NetBeacon Software](#).

**Important:** Before installing the software, make sure all the necessary JRE patches for your system are installed.

### *Sun Solaris Installation*

To install the JRE under Solaris, do the following:

1. Log on as root.
2. Create a directory called `/usr/java`, if it does not exist, by typing:  
  
**`mkdir /usr/java`**
3. Refer to the `J2re Solaris Installation Notes.htm` file, located in the `NetBeacon/Unix` directory on the NetBeacon CD, for system requirements.
4. Copy `j2re-1_4_1_02-solaris-sparc.sh` from the `NetBeacon/Unix` directory to `/usr/java`.
5. Execute `j2re-1_4_1_02-solaris-sparc.sh` from `/usr/java`.
6. Follow the on-screen instructions to complete the java installation.
7. Create an environment that will support multiple JRE installations. This is done by creating a single `/usr/java/bin` directory containing a symbolic link to a particular version of the java executable file.

```
cd /usr/java  
mkdir bin  
cd bin  
ln -s ../jre_1.4.1_02/bin/java java
```

8. Add `/usr/java/bin` to the PATH environment variable.
9. To verify that the JRE software was installed correctly, type:

```
java -version
```

You should see the following message:

```
java version "1.4.1_02"  
Java(TM) 2 Runtime Environment, Standard Edition (build 1.4.1_02-b06)  
Java HotSpot(TM) Client VM (build 1.4.1_03-b06, mixed mode)
```

## ***HP-UX Installation***

To install the JRE under HP-UX, do the following:

1. Log on as root.
2. Copy `rte14_14102_1100.depot` from the `NetBeacon/Unix` folder on the NetBeacon CD to a temporary directory.
3. Run **swinstall** on the `rte14_14102_1100.depot` file. Refer to `RTE HPUX Installation Notes.htm` for the installation procedure for the Java(tm) 2 Platform Version 1\_4\_1\_02.
4. Create an environment that will support multiple JRE installations. This is done by creating a single `/opt/java/bin` directory containing a symbolic link to a particular version of the java executable file.

```
cd /opt/java  
mkdir bin  
cd bin  
ln -s ../../java1.4/jre/bin/java java
```

5. Add `/opt/java/bin` to your PATH environment variable.
6. Verify that the Java runtime was installed properly by typing the following command:

```
java -version
```

You should see the following message:

```
java version "1.4.1.02"  
Java(TM) 2 Runtime Environment, Standard Edition (build 1.4.1.02-030502-  
13:44)  
Java HotSpot(TM) Server VM (build 1.4.1 1.4.1.02-030502-15:31-PA_RISC2.0  
PA2.0, mixed mode)
```

## ***Red Hat Linux Installation***

To install the JRE under Linux, do the following:

1. Log on as root.
2. Copy `j2re-1_4_1_02-linux-i586-rpm.bin` from the `NetBeacon/Unix` folder on the NetBeacon CD to a temporary directory.
3. Starting with step 2 in the "Installation of RPM File" section of the `J2re Linux Installation Notes.htm` file, install the JRE.
4. Create an environment that will support multiple JRE installations. This is done by creating a single `/usr/java/bin` directory containing a symbolic link to a particular version of the java executable file.

```
cd /usr/java
mkdir bin
cd bin
ln -s ../jre_1.4.1_02/bin/java java
```

5. Add `/usr/java/bin` to your PATH environment variable.
6. Verify that the Java runtime was installed properly by typing the following command:

```
java -version
```

You should see the following message:

```
java version "1.4.1.02"
Java(TM) 2 Runtime Environment, Standard Edition (build 1.4.1.02-b06)
Java HotSpot(TM) Client VM (build 1.4.1_02-b06, mixed mode)
```

### ***Windows Installation***

To install the JRE under Windows, do the following:

1. If you are installing under Windows, log on to a local Administrator account.
2. Exit any applications you have running.
3. Open the Control Panel window and double-click **Add/Remove Programs**.




The Add/Remove Programs dialog box displays the applications installed on your computer.

4. To begin the installation process, click **Add New Programs**.
5. Click **CD or Floppy**.
6. Insert the NetBeacon compact disc into your CD-ROM, and then click **Next**.
7. From the Run Installation Program dialog box, click **Browse**.
8. From the Browse dialog box, choose your CD-ROM drive and open the **NetBeacon** folder.
9. Open the **Windows** folder.
10. From the Files of Type drop-down list, choose **Programs**.
11. From the list of files, click **j2re-1\_4\_1\_02-windows-i586.exe**, and then click **Open**.



12. From the Run Installation Program dialog box, click **Finish**. The files will be extracted automatically.
13. Click **Yes** to accept the License Agreement.
14. Select either a **Typical** or **Custom** installation. If you select Typical, the JRE files will be installed in the following default location:

C:\Program Files\Java\j2re1.4.1\_02



Click **Next**. The installation process will begin and end automatically.

**Important:** Restart the computer if requested.

15. Remove the NetBeacon from the CD-ROM drive.

## Installing the NetBeacon Software

Before installing the NetBeacon software, make sure you have first installed the correct version of the JRE software. To upgrade an older version of NetBeacon, refer to [Upgrading NetBeacon](#).

To display a log of errors encountered during an installation, refer to [Viewing the Installation Error Log](#).

### *UNIX/Linux Installation*

**Important:** If you are installing NetBeacon on an HP platform, make sure that the

maximum number of threads allowed in each process is at least 1024. If the number is too low, you can use SAM (the HP-UX System Administration Manager) to change kernel parameters, following the steps described below:

1. Open **Kernel Configuration**.
2. Open **Configurable Parameters**.
3. Double-click on **max\_thread\_proc**.
4. Specify the new Formula/Value to *1024* or more.
5. Process the new kernel. The change will not take effect until the kernel is processed.

For more information regarding Java tuning, go to the HP support website (<http://www.hp.com/country/us/eng/support.html>) and type *max number of threads* in the Search field.

To install or upgrade NetBeacon under Sun Solaris or HP-UX, do the following:

1. Log on to the workstation as root. HP-UX requires the mounting of the CD drive first.
2. Insert the NetBeacon compact disc into your CD-ROM drive and go to the `NetBeacon/Unix` directory.
3. Copy the `install.jar` file to a temporary directory, and then go to that directory.
4. Type the following command:


**java -jar install.jar**

5. Go to Step 5 of the Windows Installation section below.

### ***Windows Installation***


To install or upgrade NetBeacon under Windows, do the following:

1. Log on to an Administrator account.
2. Exit any applications you have running.
3. Insert the compact disc into your CD-ROM drive. The installer will begin automatically.
4. If the installer is unable to find the required JRE version in the registry, the following error message will appear.



For further details about the error, read the information in the file `errors.log`. Refer to [Viewing the Installation Error Log](#).


5. The NetBeacon Installer window appears.



Click **Next** to continue. Click **Cancel** at any time to quit the installation. Click **Back** to return to the previous dialog box.


6. The Java Virtual Machine (JVM) verification panel displays the JRE requirements needed to install, not run, NetBeacon. Version 1.4.1 is the JRE recommended to install NetBeacon. If you have multiple versions of the JRE installed on your system, be sure to set the appropriate environment variables for path and classpath.

**Important:** The installer program does not verify that you have the correct version of the JRE needed to *run* the NetBeacon application. Refer to System Requirements for the specific version required for your platform.



Click **Next** to check your system's JVM specifications.

7. If the JVM requirements are met, the results are displayed and you can click **OK** to continue.



If the JVM requirements for the installer program are not met, an error message appears. Click **OK**. You must install the required JRE software before continuing. Refer to [Installing the Java Runtime Environment](#) for detailed instructions.

8. Next, the software license agreement terms are displayed. Read the agreement, then click **I Agree**.
9. Select one of the two options for installing the NetBeacon software.


### 30-Day Trial Installation

Select the first option and click **Next** if you want to install a temporary version of the software now and register later. Metrobility allows a 30-day trial period for use of NetBeacon before the software **MUST** be registered. The license key can be entered later through the NetBeacon client application without reinstalling the software.


### Official Installation

To install an official version of NetBeacon, you must first register your software by going to [www.metrobility.com/support/licensing/licensekey.asp](http://www.metrobility.com/support/licensing/licensekey.asp). Complete the required fields on the website and you will receive a license key via e-mail within 10 minutes of submitting. (Registering the software requires the NetBeacon serial number, which is located on a sticker on the CD.)

To install an official version of the software, select the second option. Two new fields will appear. Enter the *license key code*. Type the *name* of the individual or organization to which the software is licensed. Then click **Next**.



10. You now select one or more options for installation.



- To install both the NetBeacon server and client as a single program on one workstation, choose **Client-Server**, and then click **Next**.

**Important:** Do not select this option if you want to install the database version of NetBeacon.


- To install NetBeacon as two separate programs, select both **Server** and **Client**, then click **Next**. The NetBeacon server application will be installed first, followed by the client application.
- To install only the NetBeacon server application, choose **Server**, and then click **Next**.
- To install only the NetBeacon client application, choose **Client**, then click **Next**.

**Important:** If you are installing only the NetBeacon client, make sure the NetBeacon server application has already been installed, either locally or elsewhere on the network.

11. The name of the application that will be installed appears on the screen. Click **Next** to continue.

12. If you are not installing the database version of the NetBeacon server application, go to the next step.

If you are installing the database version of the server software, the following dialog box appears.




Select **Database Plugin** to enable NetBeacon to collect and display network data. Then click **Next**.

13. The Installation directory panel displays the default directory where the software will be installed. You may change this destination or accept the location as shown.

Under Windows, the default installation directories are `C:\NBeacon` for the combined client/server application, `C:\NBServer` for the server application, and `C:\NBClient` for the client application.

Under UNIX, the default installation directory is `/opt/NBeacon` for the client/server application. It is `/opt/NBClient` for the client application and `/opt/NBServer` for the server application.

If you are upgrading from a previous version, select the directory where the existing NetBeacon installation is located. All profiles and e-mail configurations will be transferred to the new application. The new installation will be placed in the same directory where the original software was installed.




To use the default location, click **Next**.

To change the destination, do one of the following:


- Type the *name* of the directory and then click **Next**.
- Click **Browse**, select the name of the folder using the Select a Directory dialog box, click **Open**, and then click **Next**.

14. If you selected an existing directory, the following message appears. Click **Yes** to install the software there, or click **No** to return to the previous dialog box. Click **Yes** if you are upgrading NetBeacon.



15. If you are installing the NetBeacon server application, go to [Step 17](#).

For the client or client/server installation, the following dialog box appears.



**Important:** If you are installing under UNIX, you must be logged in as root to be able to integrate properly with HP OpenView. The HP OpenView option is not available for Linux systems.

Do one of the following:


- Check **Integrate with HP OpenView Network Node Manager**, type the *directory* where the HP OpenView Network Node Manager software is located, and then click **Next**. The default directory is C:\Program Files\HP OpenView\NNM.

HP OpenView Location C:\Program Files\HP OpenView\NNM

- Check **No HP OpenView Integration**, and then click **Next**.

16. If you are installing the client/server application, go to [Step 17](#).

For the client installation, the NetBeacon server must be identified.



Type the *IP address* or *hostname* where the NetBeacon server resides, and then click **Next**. This field may be left empty.


If there was no entry in the textbox when **Next** was clicked, the following message appears.



- Click **Use default of "localhost"** if you want the client to use your workstation's NetBeacon server.

- Click **Re-enter Server Address** to return to the previous dialog box.

17. The Installing panel displays the status of the installation process.



When the installation is complete, click **Finished**. Under Windows, a set of shortcuts is added to the Start menu.

**Important:** You do *not* need to restart your computer after installing the NetBeacon software.

## Upgrading NetBeacon

If your system is running a prior version of NetBeacon, you may save your current user profiles and e-mail configurations for use in the current NetBeacon release by following the upgrade procedure outlined below.

**Important:** Do NOT uninstall NetBeacon 1.x or 2.x prior to installing the new version of the software. All configuration information will be lost if you uninstall it first.

1. Exit any applications that may be referencing the existing NetBeacon directory, and shut down any open NetBeacon client and server applications.

**Important:** The NetBeacon 1.x server does not include a graphical user interface. It is important to terminate the server process prior to upgrading to and starting this version of NetBeacon. The server process can be terminated through the Task Manager on Windows, or by using a "kill" command on UNIX. The process name will include "javaw.exe" on Windows and "java" on UNIX. The NetBeacon 1.x server process can also be terminated by rebooting the machine.

2. Install the new NetBeacon software according to the procedure listed for your specific platform. Refer to [Installing the NetBeacon Software](#).
3. When asked to specify the location where the software should be installed, select the existing NetBeacon directory.

During the installation, your current user profiles and trap e-mail configurations are transferred and all the previous NetBeacon files, menu items, and registry entries are



deleted. The resulting NetBeacon software is installed in the same directory where the existing NetBeacon files were located.

## Viewing the Installation Error Log

Specific information about errors that are encountered during installation is recorded in the file `errors.log`. This file is only created when launching the NetBeacon installer from a read/write directory. UNIX installers are normally launched from a local read/write directory, however, Windows installers are normally launched directly from the CD. To enable creation of this file under Windows, you must first copy the `install.exe` file from the CD to a read/write directory. If you then launch the installer from that directory and encounter errors, the file `errors.log` will be written to the directory where the installer was launched.

## Uninstalling the NetBeacon Software

This procedure describes how to uninstall the NetBeacon application.

**Important:** Before uninstalling NetBeacon, you must first shut down all NetBeacon client and server applications.

### *UNIX Uninstall*

**Important:** If you uninstall the JRE first, you will not be able to uninstall NetBeacon properly.

To uninstall NetBeacon from Sun Solaris or HP-UX, do the following:

1. Log on to the workstation as root.
2. Open a terminal window.
3. Go to the directory where you installed the NetBeacon files. The default directory is:

```
/opt/NBeacon for the client/server application,  
/opt/NBServer for the server application,  
/opt/NBClient for the client application.
```

4. Delete the NetBeacon directory and all its files.

**Important:** Deleting the NetBeacon directory deletes all existing profile configuration data. This data will then be unavailable for use in a new installation. Refer to the method below if you want to save this data.

Or:

1. Go to the directory where you installed the NetBeacon files. The default directory is:

```
/opt/NBeacon for the server and client/server applications;
```

`/opt/NBClient` for the client application.

2. Type one of the following commands:

- **uninstallNetBeacon** to remove the client/server software,
- **uninstallNetBeaconClient** to remove the client software,
- **uninstallNetBeaconServer** to remove the server software.

3. In the message box that appears, click **Yes** to remove the NetBeacon files.

4. After the uninstall process is done, click **Finished**.


This procedure does not remove all files. The remaining files, which include user profiles and e-mail configurations, can be deleted manually or maintained if you plan to reinstall NetBeacon.

### *Windows Uninstall*

**Important:** If you uninstall the JRE first, you will not be able to uninstall NetBeacon properly.

To uninstall NetBeacon from Windows, do the following:

1. Click Start and then choose **Programs**.
2. From the Programs list, select the **NetBeacon** program.
3. From the directory list, choose **Uninstall NetBeacon**.
4. Click **Yes** to begin the removal process.
5. After NetBeacon is uninstalled, click **Finished**.



The uninstall procedure does not remove all application files. For example, user profiles and message logs are not deleted. If you reinstall NetBeacon, these files can be used again.

6. To remove the remaining files, delete them manually using an Explorer window. If you installed NetBeacon in a different directory, any remaining files will reside in that directory.

Or:

1. Open a Control Panel window and double-click **Add/Remove Programs**.
2. Select the **NetBeacon** application that you want to remove, and then click **Remove**. Continue with [Step 4](#) above.

## What's Next?

Now that you have installed NetBeacon successfully, you are ready to begin.

[Chapter 2. NetBeacon Basics](#) provides an overview of the NetBeacon window and menus. Read chapter 2 to learn about the user interface, how to start and exit the application, and how to use NetBeacon efficiently.

[Chapter 3. NetBeacon Setup](#) describes how to set up your devices through NetBeacon, including how to establish user profiles and passwords, and customize your display.

[Chapter 4. Managing the Devices](#) provides information on specific management features, including step-by-step procedures for configuration and monitoring operations.

[Chapter 5. Configuring Modules and Ports](#) contains detailed instructions to monitor statistical information and configure the various types of cards and ports.



## Chapter 2. NetBeacon Basics

---

Chapter 2 provides useful information for network administrators who are just beginning to use the NetBeacon management software. This chapter provides information on the following topics:

- [Starting NetBeacon from Windows](#)
- [Starting NetBeacon from Linux](#)
- [Starting NetBeacon from Sun Solaris and HP-UX](#)
- [Exiting NetBeacon](#)
- [Checking the NetBeacon Version Number](#)
- [Learning about the NetBeacon Window](#)

### Starting NetBeacon from Windows

**Tip:** To optimize NetBeacon startup when you are running under Windows and do not have a Domain Name Server (DNS), add the IP address of each Metrobility chassis to the Hosts file before you add your devices. Refer to your Windows documentation for information regarding its Hosts file directory.

#### *Opening the NetBeacon Server Application*

To start the NetBeacon server or client/server application under Windows, do the following:

1. Click **Start** and then choose **Programs**.
2. From the Programs list, select **NetBeacon Client-Server 3.4.0** or **NetBeacon Server 3.4.0**.
3. From the NetBeacon directory, choose the **NetBeacon Client and Server** or **NetBeacon Server** application.

If you opened the server application, the NetBeacon Server button will be added to the Windows taskbar at the bottom of the screen.



If you opened the client/server application, the NetBeacon main window will also appear now.


## Opening the NetBeacon Client Application

Before starting the client application, make sure the NetBeacon server you want to connect to is running.

To start the NetBeacon client application under Windows, do the following:

1. Click **Start** and then choose **Programs**.
2. From the Programs list, select **NetBeacon Client 3.4.0**.
3. From the NetBeacon Client 3.4.0 directory, choose the **NetBeacon Client** application.

If the NetBeacon server is shut down when you try to start the client application, the following message appears.



Do one of the following:

- Click **Yes** to connect to a different server. Type the new server's *IP address* in the text box that appears, and then click **OK**.
- Click **No** to quit.
- Click **Retry** to attempt another connection with the same server.

## Starting NetBeacon from Linux

To start the NetBeacon application under Linux, do the following:

1. Open a terminal window.
2. If you installed NetBeacon using the default directories, type one of the following commands at the prompt:

**sh /usr/NBeacon/NBeacon.sh** to start the NetBeacon client/server or server application.

**sh /usr/NBClient/NBClient.sh** to start the NetBeacon client application.

If you did not use the default directories, replace **/usr/NBeacon** and **/usr/NBClient** with the location where you installed the NetBeacon software in the commands above.

## Starting NetBeacon from Sun Solaris and HP-UX

To start NetBeacon under UNIX, do the following:

1. Open a terminal window.
2. If you installed NetBeacon using the default directories, type one of the following commands at the prompt:

**/opt/NBeacon/NBeacon.sh** to start the NetBeacon client/server or server application.

**/opt/NBClient/NBClient.sh** to start the NetBeacon client application.

If you did not use the default directories, replace **/opt/NBeacon** and **/opt/NBClient** with the location where you installed the NetBeacon software in the commands above.

### *HP OpenView Network Node Manager*

Operating Systems

- Windows NT
  - Sun Solaris 8
  - HP-UX 11.00
1. Start HP OpenView Network Node Manager. The Radiance/Lancast device icons appear as connectors (buttons or icons) on the HP OpenView map.



**Tip:** Not all connector icons that appear on the map represent Radiance or Lancast devices.

2. Do one of the following:
    - Click the icon, and then choose **NetBeacon** from the Tools menu.
- Or:
- Double-click any Radiance or Lancast device button on your HP OpenView map.



**Important:** You must associate the NetBeacon application to the selected device, before you start NetBeacon this way.

To create an association, do the following:

1. Right-click the Radiance or Lancast device icon.


2. From the menu, choose **Symbol Properties**.

The Symbol Properties dialog box appears.



3. From the Behavior panel, click **Execute**.
4. Click **Target Objects**.

The Target Objects dialog box appears.




5. Click **Add**, and then click **OK**.

The IP address of the selected device is added to the list of target devices.

6. From the Application Actions panel, select  
**NetBeacon:runNetBeacon**





7. Click **OK**.

The Radiance or Lanecast device icon now appears as a button.

To enable a customized view of Metrobility products through NNM, refer to instructions in [Appendix D. HP NNM Customization](#).

## Exiting NetBeacon



NetBeacon is a client/server application. Under most circumstances, shutting down the server is not recommended. You should only close the client application and keep the server operating to continue monitoring devices and performing tasks for other clients.

**Important:** Exiting the server application will shut down all NetBeacon operations to all clients. Closing the NetBeacon server is NOT recommended.


### *Closing the NetBeacon Client Application*

When you exit NetBeacon, your device configuration and display settings are saved as part of your User Profile. For additional information on user profiles, see [Setting User Preferences](#).

To exit the NetBeacon client application, do one of the following:

- Click  in the upper right-hand corner of the NetBeacon window.
- Right-click the NetBeacon client button  on the task bar, and then choose **Close**.
- From the File menu, choose **Exit**.
- Press the shortcut keys ALT+F4.

When the following message appears, click **Yes**.




### *Closing the NetBeacon Server*


To shut down the NetBeacon server, do the following:

1. Close all open NetBeacon client applications. All applications must be closed before you exit the server.
2. For Windows: click the **NetBeacon Server** button on your taskbar.

For UNIX: click the **NetBeacon Server** icon on your desktop.

The following window appears.



3. Do one of the following:
  - Click **Shut Down Server**.
  - Click .
4. When the confirmation message appears, click **Yes** to exit the server. All NetBeacon operations will end.

## Checking the NetBeacon Version Number

If you have a problem using NetBeacon, you will need to know the version number of your NetBeacon software and JRE before contacting technical support. To check the firmware version on the management card, see [Displaying Management Module Information](#).


To check the software version numbers, do the following:

1. From the Help Menu, choose **About NetBeacon**.

The NetBeacon window shows the software version of your NetBeacon client, server and Java applications.




2. Click **Server Info** to display the software version of your NetBeacon server plugins, and then click **OK**.



## Learning about the NetBeacon Window

The NetBeacon main window is comprised of three frames. The top frame shows the selected device. The lower left frame lists each device on the network that is being managed through NetBeacon. The lower right frame shows the six NetBeacon folders.



Double-clicking the Metrobility or Lanecast logo in the upper left-hand corner of the chassis image connects you to the Metrobility website.

The chassis ports are green, red, blue or gray: green indicates an active link, red indicates no link, blue indicates the port is administratively disabled, and gray indicates an unknown state (this may occur at startup).

### ***Resizing the Windows and Dialog Boxes***

You can minimize, maximize, resize, and position most of NetBeacon's windows and dialog boxes. If you are running NetBeacon under Microsoft Windows, each dialog box also appears as an item in the taskbar. In the NetBeacon main window, you can resize any of the frames to enlarge or reduce the corresponding viewing area by clicking on the dividers between the frames and dragging them to the desired position. Use the scroll bars to move either vertically or horizontally across a frame. Some folders contain a series of columns that you may resize, hide and move, depending on what information you want to see (see [Customizing your Display](#)).

## Activity Indicator



The NetBeacon activity indicator is a lighthouse located at the far right of the menu bar. When you download or update information through NetBeacon, the lighthouse's background changes from day to night and a revolving light shines from the lighthouse, indicating that activity is occurring. When there is no activity, the lighthouse stands motionless in a daylight background.

## Trap Alerts

Whenever certain events occur, NetBeacon alerts you on the screen by flashing the word "TRAP!" in the menu bar, next to the lighthouse. To view a listing of the events, click the **Traps** tab. Refer to [Receiving Traps](#) for further information about traps. The trap alert does not appear if the Traps folder is open.

## ToolTips


When you pass the cursor over certain window components a ToolTip displays a brief description of that component. ToolTips are available for chassis, modules and ports in the chassis view and Devices list.

For example, if you pass the cursor over slot 17 in the chassis, which contains a management card, the following ToolTip appears:


Chassis 1, Slot 17 · Management

## Chassis View

NetBeacon provides a graphical display of the selected device, showing the complete chassis, including its power supplies. The power supplies are located in either the front of the chassis or the rear. The following illustration shows an example of a 17-slot chassis with two power supplies in the back.




**Tip:** To toggle between front and rear views, double-click the chassis view. Alternatively, right-click the chassis view and select **View Back of Chassis** or **View Front of Chassis** from the pop-up menu.








## Devices List

When you configure the NetBeacon software, you add each device you want to manage. When you add a device, its IP address is displayed in the Devices list in the lower left frame. You must select a device from this list to display its status information. The selected device is highlighted.




NetBeacon uses colored bullets to represent the status of the devices, modules, and ports. When you expand the Devices list, a chassis icon appears. To monitor the port status on any chassis in the Devices lists, expand the view to the port level.

- A green bullet indicates the following:
  - Device is being managed by NetBeacon.
  - The module has passed diagnostics and is functioning.
  - Port link is up.
- A red bullet indicates the following:
  - NetBeacon has lost communications with the device.
  - The module has failed diagnostics.
  - Port link is down.
- A blue bullet indicates the NetBeacon client is currently not monitoring the device.
-  A 12-slot chassis with power supplies in the front.
-  A 17-slot chassis with power supplies in the back.
-  A fixed port chassis with power supplies in the back.
-  A two-slot chassis with power supplies in the back.
-  A diskette next to a bullet indicates that the device is enabled for logging data to the database.

After you add your devices, you must select one before you can continue. For additional information on setting up devices, see [Adding a Device through NetBeacon](#) and [Selecting a Device](#).



## Expanding and Collapsing the Devices List

After you have selected a device, NetBeacon allows you to expand the Devices list so that it shows all of the modules and ports associated with the chassis. If a stack is included in the list, you will be able to see each chassis in that stack.



To expand the list for all of the active devices, right-click anywhere in the Devices frame and select **Expand All** from the pop-up menu.

To minimize the list so that only the devices are shown, right-click anywhere in the lower left frame and select **Collapse All**.

Click  or  to collapse or expand a particular branch of the Devices list.

## Fields and Folders

NetBeacon organizes information about the devices through the use of folders. Each folder contains different information relevant to your device selection.

You cannot change any shaded (grayed) field information; this information is for display only. You can edit field information with a white background (e.g., names of devices and modules).

Folder	Description
Information	System information about the selected device, including the name of the device, its physical location, a contact name, its description, its IP address, system uptime and services, and the software version on the management card (see <a href="#">Displaying Device Information</a> ).
Configuration	Information about the configuration of the device, including its IP address, subnet mask, default gateway, and SNMP configuration (see <a href="#">Configuring a Device</a> ).

Folder	Description
Stack	Hardware-related information about each device in the selected stack, including a description; part number; number of slots; stack position; and minimum, maximum and current temperatures (see <a href="#">Configuring a Device</a> ). A single chassis is treated as a stack of one.
Traps	Alarm messages (SNMP traps) that relate to the configuration or status change of a device, module, or port. NetBeacon lets you forward these notifications through an E-mail connection (see <a href="#">Configuring E-mail Notifications</a> ). You can also acknowledge, clear and filter traps.
Modules	Information about the replaceable cards, including the management card, installed in the chassis. Includes each card's location, name, asset ID, description, type, uptime, operating status, hardware version, date of manufacture, and part number (see <a href="#">Chapter 5. Configuring Modules and Ports</a> ).
Ports	Port information including location, name, type, speed, operational status, duplex, link status, and settings for various switches (see <a href="#">Chapter 5. Configuring Modules and Ports</a> ).

### ***Shortcut Keys***

You can choose some menu options by using either the mouse or the shortcut keys. The following table lists the menu options and their associated shortcut keys.

Option	Shortcut Keys
Import Devices from HP Openview	F2
Refresh	F5
Save Profile	CTRL+S
Exit NetBeacon Client Application	ALT+F4
Print	CTRL+P
Cut	CTRL+X
Copy	CTRL+C
Paste	CTRL+V

**Tip:** You can use the keyboard to select any menu command or option. To open a menu, press ALT and the first letter of the menu (the letter is underlined). From the menu that appears, press the underlined letter in the option that you want. For example, to change the device date and time, press ALT+D and then press C.



## Menu Bar


There are five drop-down menus, which you access from the menu bar. This section describes each menu option.

### File Menu



Option	Use this option to:
New Profile	Create a new user profile.
Open Profile	Select a user profile from a list of profiles that are saved (see <a href="#">Opening a User Profile</a> ).
Save Profile	Save the settings to the user profile currently in use (see <a href="#">Saving a User Profile</a> ).
Save Profile As	Save the user profile using a new name and switch to it (see <a href="#">Renaming a User Profile</a> ).
Delete Profile	Delete a user profile (see <a href="#">Deleting a User Profile</a> ).
Page Setup	Define basic parameters for printed reports (see <a href="#">Setting Up Pages</a> ).
Print	Print the table in the selected folder (see <a href="#">Printing NetBeacon Reports</a> ).
License	Display information about the current NetBeacon license (see <a href="#">Viewing NetBeacon License Information</a> ).
Exit	Exit the NetBeacon client application (see <a href="#">Exiting NetBeacon</a> ).

### Edit Menu



Option	Use this option to:
Cut	Delete the selected text and move it to the Clipboard.
Copy	Move the selected text to the Clipboard.
Paste	Move text from the Clipboard to the insertion point, or replace the selected text with the text from the Clipboard.

## View Menu




Option	Use this option to:
Zoom In	Display the chassis and modules in a larger format for easier reading (see <a href="#">Resizing the Chassis View</a> ).
Zoom Out	Display the chassis and modules in a smaller format (see <a href="#">Resizing the Chassis View</a> ).
Show Remotes	Show or hide any remote access line cards connected to the selected chassis.
Show ToolTips	Show or hide application ToolTips (see <a href="#">Showing ToolTips</a> ).
Table Gridlines	Show or hide vertical and horizontal table gridlines that appear within folders (see <a href="#">Changing the Appearance of your Tables</a> ).
Look & Feel	Change your NetBeacon window style to Native, Metal, or Motif, based on your viewing preference (see <a href="#">Changing the Look &amp; Feel of your Display</a> ).
Degrees	Display temperature readings in either Celsius or Fahrenheit (see <a href="#">Selecting a Temperature Scale</a> ).
Refresh	Update folder information for the selected device (see <a href="#">Refreshing the NetBeacon Window</a> ).

## Device Menu



Option	Use this option to:
Add Devices	Add a device on the network to the NetBeacon configuration (see <a href="#">Adding a Device through NetBeacon</a> ).
Delete Devices	Remove a device on the network from the NetBeacon configuration (see <a href="#">Deleting a Device</a> ).
Import Devices from HP OpenView	Add devices discovered through HP OpenView or HP Network Node Manager (see <a href="#">Adding Devices from HP OpenView or Network Node Manager (NNM)</a> ).
Reset Device	Restart the selected device. You may want to reset a device after you download new software (see <a href="#">Resetting a Device</a> ).
Ping Device	Display a command window, issuing a ping command to a device (see <a href="#">Pinging a Device</a> ).
Telnet to Device	Display a command window so you can issue commands via telnet directly to a device (see <a href="#">Opening a Telnet Session</a> and the <i>Command Line Interface ~ Reference Guide</i> ).
Download Software to Device	Download embedded software to the selected device, for example, when performing a software upgrade (see <a href="#">Downloading Software to a Device</a> ).
Change Device Date and Time	Change the device's date and time (see <a href="#">Changing the Date and Time</a> ).










## Help Menu



Option	Use this option to:
NetBeacon User Manual	Display this user's guide in PDF format. You must have the Adobe Acrobat Reader installed to view this guide.
About NetBeacon	Display the software version numbers of the NetBeacon client and server applications, JRE and plugins installed on your machine (see <a href="#">Checking the NetBeacon Version Number</a> ).

## ***Toolbar***

The icons in the toolbar represent commands commonly used in NetBeacon. Click the icon to select the command.

Icon	Command
	Create a new user profile.
	Open an existing user profile.
	Save the current user profile.
	Cut.
	Copy.
	Paste.
	Zoom in.
	Zoom out.
	Show or hide remote access line cards.

## Chapter 3. NetBeacon Setup


---

Before you begin to monitor network devices, you must configure NetBeacon by adding each device you want to manage. This chapter describes how to configure the NetBeacon software. If you are running HP OpenView, see [Adding Devices from HP OpenView or Network Node Manager \(NNM\)](#).

### Adding a Device through NetBeacon

To add a new device through NetBeacon, do the following:

1. Start NetBeacon.
2. From the Device menu, choose **Add Devices**. The Add Devices dialog box appears.



The Device List shows the IP address of each device on the network that NetBeacon is currently managing. If this is the first time you are using NetBeacon, no devices appear.

**Tip:** Another way to open this dialog box is to right-click anywhere in the lower left frame, then choose **Add Devices** from the menu.

3. In the User-Specified Device text box, type the *IP address* or *DNS name* of the device you want to add.
4. Click **Add** or hit ENTER to add the device to the list.

**Important:** If you entered a DNS name, NetBeacon tries to resolve the entry at this time. It is strongly recommended that you add the entry to your Hosts file first.

5. Repeat Steps 3 and 4 until you have added all of your devices. When you are done adding devices, click **OK**.

The IP addresses are shown in ascending order.

## Adding Devices from HP OpenView Network Node Manager (NNM)


Before you start NetBeacon, run HP NNM and discover any devices on the network (see [Starting NetBeacon from Sun Solaris and HP-UX](#)).

To import one or more devices from HP OpenView NNM, do the following:

1. Start NetBeacon from HP Openview HP NNM (see [HP OpenView Network Node Manager](#)).
2. From the Device menu, choose **Import Devices from HP OpenView**.

The Import Devices dialog box lists any device on the network that HP OpenView has discovered in the Devices Discovered by HP OpenView column. The IP addresses of the devices you add appear in the Devices to ADD to NetBeacon column.

**Important:** You must have run OpenView for the devices to appear in the Import Devices dialog box.





3. Do one of the following:
  - Select the device you want to add, and then click **Add**. To add all devices, click **Add All**.
  - Select the device you want to remove, and then click **Remove**. To remove all devices, click **Remove All**.

## Selecting a Device

You must select a device before you can retrieve any information. To select a device, do the following:

- From the Devices list, click the IP address or DNS name of the device you want to monitor.




- If you are monitoring a stack and want to select one of the chassis within it, click the IP address or DNS name of the stack. Next, expand the list by clicking  and then click the chassis to select it.

## Unmanaging a Device

To end communications with a device while still keeping it on the Devices list, do the following:

1. From the Devices list, select the device you want to stop managing.
2. Right-click and then choose **Unmanage Device** from the pop-up menu. The bullet color will change to blue, indicating that NetBeacon is no longer managing the device.



## Deleting a Device


There are two ways to delete a device. To remove a device from your NetBeacon configuration, do one of the following:

1. From the Device menu, choose **Delete Devices**.

The Delete Devices dialog box appears. The Device List shows the IP address or DNS name of each chassis on the network that NetBeacon is configured to manage.

2. From the Device List, select one or more of the devices.

**Tip:** Select multiple devices by pressing the CTRL key and clicking the IP address or DNS name of each device you want to remove.



3. Click **Delete**, then click **OK**.

Or:

1. From the Devices list, select a device.
2. Right-click and then choose **Delete Devices**.

The Delete Devices dialog box appears with the device selected.

**Tip:** Select additional devices by pressing the CTRL key and clicking the IP addresses or DNS names of any other devices you want to remove.


3. Click **Delete** to remove the device(s) from the list.
4. Click **OK**.

## Resetting a Device

To reset a device, which resets the management card, do the following:

1. From the Device menu, choose **Reset Device**.

The following message appears.



2. Click **Yes**.

**Tip:** You can also reset the device by clicking **Reset Chassis** in the Stack folder, clicking **Reset System** in the Configuration folder, or right-clicking on the management card in the chassis view and selecting **Reset Module**.




## Pinging a Device

Packet InterNet Groper (PING) is a program used to test connections on the network by sending a request and waiting for a reply. The term "ping" refers to this process. Use this command to verify the connection status of a device.

To ping a device, do the following:

1. From the Device menu, choose **Ping Device**.

The command window displays the results of the command. A successful connection displays a reply from the device that includes the IP address, the number of packets sent and received, and the roundtrip delay (shown in milliseconds).



2. To close the window, click **OK**.


## Opening a Telnet Session

You can open a telnet session from NetBeacon whenever you want to issue commands directly to a device.

**Important:** To use telnet, you must have a login ID and password on the device.

To start a telnet session, do the following:

1. From the Devices list, select the device to which to connect.
2. From the Device menu, choose **Telnet to Device**.



3. In the login field, type your *login ID*. The default login names are guest, admin and root.
4. In the password field, type your *password*. The corresponding default passwords are guest, admin and root.

To end a telnet session and close the command window, do one of the following:

- In the title bar, click .
- In the title bar, right-click and choose **X Close** from the pop-up menu.
- At the command prompt, type **quit** and hit ENTER.
- At the command prompt, type **exit** and hit ENTER.

## Downloading Software to a Device


The management module runs the SNMP software that controls the device. You can download the software with the assistance of the Metrobility Technical Support staff or you can install it directly from the NetBeacon CD.

The CD contains a directory called Firmware. This directory contains the management module software, including Release Notes.

To download software to a device, do the following:

1. From the Device menu, choose **Download Software to Devices**.

The Embedded Software Download dialog box appears.




2. Choose **Update image** to download only the image software (corepm.biz). Choose **Complete update** to download software for both the new image (corepm.biz) and the boot code (boot.bin).
3. Choose the device(s) you want to update. If the selected device is a stack, all the chassis within that stack will be updated.

**Tip:** Select multiple devices by pressing the CTRL key and clicking the IP addresses you want.

To update all devices in the Active Devices list, click **Select All**.


4. If you want NetBeacon to reboot all of the selected device(s) after downloading the software, check **Reset devices after update**.
5. Click **Update**. The following confirmation message appears.




6. Click **OK** to begin downloading.

**Important:** Do not reset or power-down the system while downloading software! The file system can go into an unknown state causing boot failures.

NetBeacon reports the download progress for each selected device in the dialog box. The overall download progress is shown below the list of active devices.



- After the download process is completed, a message in green text appears for each device successfully updated.



- Click **Close**.


Refer to [Appendix C. Download Error Messages](#) if you receive an error message.

## Changing the Date and Time

To change the date and time of the device, do the following:

- From the Device menu, choose **Change Device Date and Time**.

The dialog box shows the current date and time set for the device.



- In the New device date and time (GMT) text box, type the date and time using the format **yyyy-mm-dd hh:mm:ss**. (This is 24-hour Greenwich mean time, using an hour from 00 to 23.)
- Click **OK**.

## Customizing your Display

NetBeacon provides several ways to change the way data is displayed on the screen. This section describes how to change the chassis view, show ToolTips and table gridlines, and display NetBeacon with a Native, Metal, or Motif appearance.

### *Resizing the Chassis View*

Depending on the size and current settings of your monitor, you may want to enlarge or reduce the size of your chassis image.

Zooming in displays the modules in the chassis in a larger format so they are easier to read. Zooming out displays the modules in the chassis using a smaller view, allowing you to see more of the folder contents.


NetBeacon provides two ways to zoom in and out. Do one of the following:

- From the View menu, choose **Zoom In** or **Zoom Out**.
- From the toolbar, click the magnifying glass with the "+" to zoom in or the "-" to zoom out.



### Showing Remote Access Line Cards

Remote access line cards are shown below the chassis. To display remote cards connected to a chassis, do one of the following:

- From the View menu, choose **Show Remotes**. A checkmark appears next to the menu option when it is activated.
- From the toolbar, click the remotes icon  to alternate between hiding and showing remote access line cards.



Remote Access Line Card

## Showing ToolTips

ToolTips provide a brief description of the currently selected window component.

To display ToolTips, do the following:

1. From the View menu, choose **Show ToolTips**.

A checkmark appears to the left of the menu option when ToolTips are active.

A screenshot of a menu item labeled 'Show ToolTips' with a checkmark to its left.

2. To display ToolTip information, pass the cursor over a component in the chassis view or Devices list.

**Tip:** To hide ToolTips, choose **Show ToolTips** from the View menu and remove the checkmark.

## Changing the Appearance of your Tables

The Stack, Modules, and Ports folders display information in the form of tables. Depending on your personal preference or on the Look & Feel you are using, you may want to turn the table gridlines on or off, hide some of the columns, or resize the table.

To display gridlines, do the following:

- From the View menu, choose **Table Gridlines**.



You may hide or show both vertical and horizontal lines. A checkmark appears to the left of the menu option when gridlines are active.

**Tip:** To hide gridlines, choose **Table Gridlines** and remove the checkmark from the menu option.

To hide a column in a table, do the following:

1. Right-click in the column you want to hide.
2. Click **Hide Column "column name."** Hiding a column in a table affects all chassis in all profiles.

**Tip:** To add the column back into the table, right-click anywhere in the table, select **Show Column "column name,"** and click on it. The column reappears as the *rightmost* column in the table.

To resize a column, do the following:

- Click on the right border of the column heading and drag the cursor until the column is the desired size.


### ***Changing the Look & Feel of your Display***

You can change the way the NetBeacon window appears, based on your personal preference. You can choose a Native (default), a Metal, or a Motif Look & Feel.

The Native appearance of the Look & Feel selection differs for each platform, providing a graphical interface that is typical for each platform. You can also force the NetBeacon window to a Metal or Motif appearance.

To change the NetBeacon display, do the following:

1. From the View menu, choose **Look & Feel**.



2. Choose the display type you want to use: Native, Metal, or Motif. A bullet appears to the left of the menu option when it is active.

**Tip:** When either Metal or Motif is active, use the SPACE bar instead of the ENTER key for button activation in dialog boxes.

### ***Selecting a Temperature Scale***

NetBeacon displays all temperatures using either the centigrade or Fahrenheit scale. The Fahrenheit scale is used by default. To switch scales, do the following:

1. From the View menu, choose **Degrees**.
2. Click on either **Celsius** or **Fahrenheit**. A bullet appears to the left of the active scale.



After converting from one scale to another, graphical temperature gauges must be closed and reopened before the change takes effect.

### ***Refreshing the NetBeacon Window***

As you work, you may want to refresh the NetBeacon window after making changes to a device. Refreshing the NetBeacon window updates the folders and the chassis view with the most current information from the device. To refresh the NetBeacon window, do one of the following:

- From the View menu, choose **Refresh**.

- Press F5.

## Printing NetBeacon Reports

NetBeacon provides an option to print reports in a table format for each of the six folders (Information, Configuration, Stack, Traps, Modules, or Ports).

1. Select a device from the Devices list.
2. Click the folder tab containing the information you want to print.
3. Click the **Print** command button, or select **Print** from the File menu.
4. Set your print options, and then click **OK**.

## Setting Up Pages

Before printing a NetBeacon report, you may want to define some basic parameters for the page. To set up pages, do the following:


1. Choose **Page Setup** from the File menu.
2. Specify the options such as paper size, orientation, and margins. The choices available will depend on the platform you are using. Then click **OK**.

## Setting User Preferences

A user profile defines the configuration settings, such as the device list and display settings, for a specific user. A default profile is used the first time you start NetBeacon. As you configure NetBeacon, you can create new profiles or change an existing profile. This allows multiple users to each maintain a unique setting or a single user to save different settings.

**Important:** On a shared NetBeacon server, the same default profile is accessible by all its clients. Changes to the default profile made by one client will affect every user's default the next time they log in. To protect your settings, create a new profile.

The active user profile name is displayed in the title bar.




The user profile contains the following information:

- IP addresses of the devices NetBeacon manages
- Settings for ToolTips, Table Gridlines, Look & Feel and Degrees



## *Saving a User Profile*

As you configure NetBeacon, you should save your changes for future sessions. To save your user profile using the same name, do one of the following:


- From the File menu, choose **Save Profile**.
- Press the shortcut keys CTRL+S.
- Click the Save Profile icon  in the toolbar. When the confirmation message appears, click **OK**.

## *Renaming a User Profile*


To change the name of the active user profile, do one of the following:

1. From the File menu, choose **Save Profile As**.

The Save Profile As dialog box appears.



2. In the Profile Name text box, select a name from the drop-down list or type a new *name* for the profile you want to rename. If you enter a new name, a new user profile is created.
3. Click **OK**.
4. If you are applying changes to an existing profile, the following message appears.



Click **Yes** to overwrite the current profile.

5. Click **OK** after the confirmation message appears.


**Tip:** If you want to assign a password for the profile, see Setting Your Password.

## Creating a New User Profile

A new profile is not configured to monitor any devices and uses only default settings. After you create a new profile, you must add the device(s) you want NetBeacon to manage. To create a new user profile, do the following:

1. From the File menu, choose **New Profile**.

The New Profile dialog box appears.

**Tip:** Click the New Profile icon  in the toolbar to display the New Profile dialog box.

2. In the Profile Name text box, type the *name* of the new user profile you want to create, then click **OK**.


**Tip:** If you want to assign a password for the profile, see Setting Your Password.


## Opening a User Profile

To switch to another user profile that has already been created, do the following:

1. From the File menu, choose **Open Profile**.

The Open Profile dialog box appears.



**Tip:** Click the Open Profile icon  in the toolbar to display the Open Profile dialog box.


2. From the list, select the user profile to open, and then click **OK**.
3. If the profile has password protection, NetBeacon asks you for the password. Type the *password* and then click **OK**.

## ***Deleting a User Profile***


To delete a user profile, do the following:

1. From the File menu, choose **Delete Profile**.

The Delete Profile dialog box appears.



2. From the list, select the user profile to delete.
3. Click **Delete**.
4. When the confirmation message appears, click **Yes**.
5. If the profile has password protection, NetBeacon asks you for the password.



Type the *password* and then click **OK**.

6. Click **OK** to close the Delete Profile dialog box.

## ***Setting Your Password***

Passwords are used to secure your profile so that only authorized users have access to the devices loaded in the profile through NetBeacon.

To set your password, do the following:


1. From the File menu, choose **Save Profile As** or **New Profile**.
2. Check the **Requires Password Protection** box.



3. In the Profile Name text box, type the *name* of the new profile or choose one from the drop-down list.
4. In the Profile Password field, type your *password*.
5. In the Profile Re-Enter Password field, type your *password* again.
6. Click **OK**.

## Viewing NetBeacon License Information

To view information about the NetBeacon software license, choose **License** from the File menu. The NetBeacon License dialog box displays the current license key code, the expiration date (if you have a trial or demo version), and the name of the person to whom the software is licensed.



### *Updating the NetBeacon License*

The license key and the name of the licensee may be modified.

1. Click **Update** from the NetBeacon License dialog box shown above.
2. In the License key field, type your *license key code*.
3. Enter a *name* in the Licensed to textbox.
4. Click **OK**.

## Configuring the Database


**Important:** This section is only applicable to the database version of NetBeacon.

With the database plugin installed, NetBeacon provides several options that determine how and when data is logged on each device. To set up database management, do the following:

1. Under Windows: click the **NetBeacon Server** button on your taskbar.

Under UNIX: click the **NetBeacon Server** icon on your desktop.

The NetBeacon Server dialog box appears.



2. Click **Database Options**. In the Database Administration dialog box, the Devices list displays the IP address or DNS name of each device configured for database management. If this is the first time you are using NetBeacon, no devices are shown.



The status of the devices can be determined by the color of the text. Initially, all devices are shown in blue. Green and red text only appears after a device is enabled to record data.

**Blue** The device has not been scheduled for discovery yet, is in the discovery process, or has been disabled from logging data.

**Green** NetBeacon has discovered the device successfully and is recording data for this device.


**Red** The device is enabled to log data, but NetBeacon failed to reach the device.

Additionally, if the device is enabled to log data, you will see *\*Recording\** next to it.

### ***Adding a Device for Database Management***

You can add new devices to the database management list either individually or collectively. To add a new device, one at a time, do the following:

1. From the Database Administration dialog box, click **Add**. The Add Devices dialog box appears.



2. In the User-Specified Device text box, type *the IP address* or *DNS name* of the device you want to add.
3. Click **Add** or hit ENTER to add the device to the list.
4. Repeat steps 2 and 3 until you have added all your devices.
5. Click **OK**.

### ***Updating the Database Devices List***

To add multiple devices from one or more NetBeacon client(s) for database management, do the following:

1. From the Database Administration dialog box, click **Add**.
2. Click **Update device list**. The following message appears.



3. Click **Yes**. The NetBeacon server adds every active device being monitored by each of its clients to the list.

**Important:** Only active devices are added to the list. Devices with an inactive or unknown status are NOT included.

4. Click **OK** to add the list of devices to the database.

### ***Removing Database Devices***

To remove devices from the database management list, do the following:

1. Open the Database Administration dialog box.
2. Do one of the following:
  - Click the device to remove from the list.
  - To select more than one device, press the CTRL key and click each device you want to remove.
  - To select a group of adjoining devices in the list, press the SHIFT key and click the first and last devices in the group. Everything between the two devices will be highlighted.
  - Click **Select All** if you want to delete all devices in the list.
3. Click **Remove**.
4. Click **Yes** when the confirmation message appears.

### ***Logging Data***

After you have specified the devices for database management, you can enable them to log data.

1. To enable a device, select it from the list in the Database Administration dialog box.

**Tip:** Click **Select All** if you want to enable all the devices in the list at once.
2. Click Enable.
3. Click Yes. Enabling a device starts its discovery process. You will see *\*Recording\** next to each device enabled for logging.

**Tip:** In the NetBeacon Devices list, the disk icon  next to a device indicates that the device is enabled for logging data.




## Creating Database Archives

NetBeacon maintains a database for each device enabled to log data. The database contains information from the present to a maximum of 28 days. As new information is added to the database, older data is dropped due to storage considerations. To preserve data that is older than 28 days, NetBeacon provides a mechanism that produces database archives.

Database archives are data files that can easily be moved to a different location, read into another database, or imported by other applications. These files also require significantly less storage space than the database they represent.

To create database archives, do the following:

1. Select one or more devices from the list in the Database Administration dialog box.
2. Click **Archive**. The Archive Devices dialog box appears with the selected device(s) highlighted. If multiple devices are selected, their archives will all contain data for the same specified period of time.



3. Specify the time span for the database archives. The dates must be 28 days apart or less. The start and stop dates use the format yyyy/mm/dd, where yyyy is the year, mm is the month, and dd is the day.

To change the date, click on a number and do one of the following:

- Type a new number.
  - Use the arrows at the right of the text box to increase or decrease the number.
4. Click **Archive**. The progress indicator displays the percentage of the process that has been completed. When done, it reports Archive Progress:Completed.
  5. For additional information about database archives, refer to [Appendix B. Database Archives](#).



## Chapter 4. Managing the Devices

This chapter describes the NetBeacon management features and how to use them to monitor the devices on your network.

**Important:** You cannot change any folder information that is shaded (grayed); this information is for display purposes only.

### Displaying Device Information

The Device Information folder displays system information about the selected device, including the device's name, location, contact, description, and IP address.

The only information you can change is the device name, location and contact.

**Tip:** Changes are displayed in blue until they are applied.

To view information about a device, do the following:

1. From the Devices list, select the device.
2. Click the **Information** tab to display the Device Information folder.

Do one of the following:

- Click **Apply** to confirm any changes, then click **OK**.
- Click **Cancel** to discard your changes.
- Click **Refresh** to display the current information configured on the device.
- Click **Print** to print the information contained in this folder.

The following table lists the information shown in this folder, along with a brief description of each field.

Name	Description
Device Name	Name of the device.
Device Location	Physical location of the device.
Device Contact	Person or group to contact regarding the device.
Description	A description of the device.
IP Address	The IP address of the device.
System Up Time	The length of time that the system has been running since it was last reset.
System Services	The system-level services available on the device.
System OS Version	The software version on the management card.

## Configuring a Device

When you first configure a device, you identify its IP address, subnet mask, and default gateway through a local console. Subsequent to this initial configuration, you can use NetBeacon to change the configuration.

To configure a device, do the following:

1. From the Devices list, select the device to configure.

**Important:** The device must have an IP address and be accessible on the network before it can be configured.

2. Click the **Configuration** tab.

The Configuration folder displays the Management Configuration parameters (top) and the SNMP Configuration parameters (bottom).

The screenshot shows the 'Configuration' tab of the NetBeacon interface. At the top, there are tabs for 'Information', 'Configuration', 'Stack', 'Traps', 'Modules', and 'Ports'. Below these, a dropdown menu shows 'System: 192.132.65.76'. The main area is divided into two sections: 'Management Configuration' and 'SNMP Configuration'. The 'Management Configuration' section includes fields for 'IP Address' (192.132.65.76), 'Subnet Mask' (255.255.255.0), and 'Default Gateway' (192.132.65.1). The 'SNMP Configuration' section includes fields for 'SNMP Retry Count' (2), 'SNMP Timeout' (10), 'READ Community' (public), 'WRITE Community' (\*\*\*\*\*), and 'WRITE Community Confirm' (\*\*\*\*\*). At the bottom, there are buttons for 'Apply', 'Cancel', 'Refresh', 'Reset System', and 'Print...'.

3. For devices with a dual Ethernet interface management card or that are in a stack, a drop-down menu appears in the upper right corner of the Configuration folder. The menu contains the IP addresses of every Ethernet port on all the management cards in the chassis or stack. Select an IP address from the menu to display its management and SNMP configuration.

4. To change the management configuration of a device, do the following:

- In the IP Address text box, type the new *IP address* of the device.

NetBeacon removes the old IP address and adds the new one, while maintaining all communications with the device.

- In the Subnet Mask text box, type the *subnet mask* of the device.
- In the Default Gateway text box, type the *gateway* of the device.

Setting the default gateway allows the device to send packets beyond its subnet.

**Warning:** Setting an invalid IP address, mask, or gateway may cause you to lose contact with the device.

**Important:** Initially, the IP address, subnet mask, and default gateway (optional) are configured through the command line interface as described in the *Command Line Interface ~ Reference Guide*.

The following table lists the Management Configuration information shown in this folder, along with a brief description of each field.

Name	Description
IP Address	The Internet Protocol (IP) address uniquely identifying the device as a node on the network.
Subnet Mask	A bit mask identifying which bits in the IP address correspond to the network and subnet portions of the device IP address.
Default Gateway	The IP address of the router connecting to other networks on the device's network. The default gateway is necessary for the device to send packets to nodes on subnets other than its own.

5. To tune the SNMP Configuration of NetBeacon, do the following:

- In the **SNMP Retry Count** text box, type the *number of times* NetBeacon can retry SNMP requests before deciding that the device is not reachable.
- In the **SNMP Timeout** text box, type the *number of seconds* NetBeacon waits for a response before reissuing a request.
- In the **READ Community** text box, type a unique *string* to authorize read access to the device.

- In the **WRITE Community** text box, type a unique *string* to authorize write access to the device.
- In the **WRITE Community Confirm** text box, retype the *string* to authorize write access.

**Important:** Changing the READ or WRITE Community string can affect communications between the management card and the device. If you attempt to connect, NetBeacon prompts you for the correct community string.

6. Do one of the following:

- Click **Apply** to confirm any changes to the device configuration.
- Click **Cancel** to discard your changes.
- Click **Refresh** to display the current information configured on the device.
- Click **Reset System** to reboot the device.
- Click **Print** to print the information contained in this folder.

The following table lists the SNMP Configuration information shown in this folder, along with a brief description of each field.

Name	Description
SNMP Retry Count	The number of times NetBeacon retries an SNMP request before deciding the device is not available.
SNMP Timeout	The number of seconds NetBeacon waits for a response before reissuing a request.
READ Community	A unique string authorizing SNMP read access to the device.
WRITE Community	A unique string authorizing SNMP write access to the device.
WRITE Community Confirm	A confirmation of the string entered in the WRITE Community field.

## Monitoring the Chassis

The Stack folder displays information about all the chassis in the stack. For a device that is not a stack, only a single chassis is listed in the folder.

System: 192.132.35.170									
Location	Name	Asset ID	Description	Part Number	Number of Slots	Position	Min Temp	Max Temp	Temp
Chassis 1	Chassis1		17 Slot Chassis 19"	R5000-17HS	17	1	32°F	131°F	90°F
Chassis 2	Chassis2		17 Slot Chassis 19"	R5000-17HS	17	2	32°F	131°F	111°F
Chassis 3	Chassis3		2 Slot Chassis	R400-02HS	2	3	32°F	131°F	86°F

The following table lists the chassis information shown in this folder, along with a brief description of each field.

Name	Description
Location	The location of the chassis.
Name	The name of the chassis.
Asset ID	User-defined asset tracking identifier.
Description	Details on the type of chassis.
Part Number	The part number assigned to the chassis for identification purposes.
Number of Slots	The number of slots the chassis contains.
Position	Position of the chassis in the stack. Position is "0" if the device is not part of a stack.
Min Temp	The lowest temperature at which at the device can operate properly.
Max Temp	The highest temperature at which at the device can operate safely.
Temp	Current temperature of the device.

### *Displaying Chassis Information*

To display chassis information, do the following:

1. From the Devices list, select the device.
2. Click the **Stack** tab.
3. From the Stack folder, select a chassis by double-clicking on it.

The Chassis Information dialog box appears. The top half of the dialog box displays information relating to the chassis hardware.

To change the name and asset ID of the chassis, type them in the textboxes and click **Apply**. Click **OK** when the confirmation message appears.

The screenshot shows a window titled "Chassis Information for Stack 192.168.3.163". Inside, there's a section labeled "System: 192.168.3.163" and "Chassis Information". Below this, there are two columns of fields. The left column contains: Name (with "Chassis" entered), Description (with "17 Slot Chassis 19" entered), Number of Slots (with "17" entered), and Manufacture Date (with "05/03/2001" entered). The right column contains: Asset ID (empty), Part Number (with "R5000-17HS" entered), Serial Number (with "B011800361" entered), and Revision Number (with "B" entered).

**Tip:** An alternate method to display the Chassis Information dialog box is to right-click the chassis icon in the Devices list and select **Show Dialog** from the drop-down menu.

4. Do one of the following:

- Click **Refresh** to update the information shown for the chassis.
- Click **Reset Chassis**.
- Click **Reset To Default** to reset the chassis to its default settings.


The following table lists the Chassis Information shown in the top half of this dialog box, along with a brief description of each field.

Name	Description
Name	The name of the chassis.
Asset ID	User-defined asset tracking identifier.
Description	Details on the type of chassis in which the modules are installed (for example, number of slots and type).
Part Number	The part number assigned to the chassis for identification purposes.
Number of Slots	The number of slots the chassis contains: 2, 12 or 17.
Serial Number	The serial number assigned to the chassis for identification purposes.
Manufacture Date	The date the chassis was manufactured.
Revision Number	The version of the chassis backplane.

### ***Displaying Temperature and Power Supply Information***

The bottom half of the Chassis Information dialog box displays environmental information, including the temperature of the chassis, the voltage supplied by each power supply, and the operating status of each power supply. Voltage and temperature information are displayed using both a graphical and textual format.

**Tip:** Passing the cursor over the temperature gauge displays a tooltip that converts the current temperature from degrees Celsius to Fahrenheit or vice versa.




The following table describes the power supply information.

Name	Description
Supply #	A device may have one or two power supplies, denoted Unit A (on the left) and Unit B (on the right).
Status	Operational status of the power supply, either ON or OFF.
Type	Type of power supply: AC or DC.
Minimum Volts	A predefined value representing the minimum voltage that the power supply should provide.
Current Volts	The current voltage output by the power supply.
Maximum Volts	A predefined value representing the maximum voltage that the power supply should provide.

Click the **Temperature History** or **Voltage History** button to view a graphical display of the chassis' temperature or power supply voltage over an extended period of time. (This feature requires the device to be enabled for recording data, using the database version of NetBeacon.)

**Tip:** Double-clicking on a gauge also displays its associated history graph.



To change the maximum time interval shown in the graph, choose one of the options from the Time Span drop-down list.

**Important:** You may notice that the graph line does not begin at 0. Some time lag is natural in NetBeacon graphs. When data is collected only once every 15 minutes, the latest data point may be as much as 15 minutes old. Make sure the clocks on the client and server are synchronized and set to the correct local time zone.

## Receiving Traps


The Traps folder displays a message (SNMP Trap) whenever certain events occur in any of the devices being monitored. NetBeacon provides numerous traps, including notification of configuration and status changes or problems with a power supply, chassis, module, or port.

For example, a message can be sent if the power supply goes above or below the acceptable voltage range or if the temperature of the chassis rises above the recommended operating temperature.


**Important:** When recording events, NetBeacon uses the local PC time and not the time from the device.

## Monitoring Traps

To display trap alerts, click the **Traps** tab. The Trap Information folder displays each message in a scrollable window.



The following table lists and describes the Trap Information fields shown in this folder.

Name	Description
Flag	 indicates a new message which has not been acknowledged.
Alert	A brief description of the trap.
Device	The IP address of the device where the trap was generated.
Date/Time	The date and time when the event occurred.



One or more messages may be acknowledged by selecting the message(s) and clicking **Acknowledge Traps**. Acknowledging a message removes the blue NEW icon at the far left of the table, but the message remains on the list. To acknowledge all new messages, click **Acknowledge All Traps**.


Select one or more messages and click **Clear Traps** to delete them permanently from the list. To remove all messages, click **Clear All Traps**.

### *Displaying the Trap Legend*

NetBeacon has two categories of traps: Generic Traps and Enterprise Traps. Initially, all available trap messages (except Generic EGP Neighbor Loss) are enabled. However, you can disable individual messages to suit your network monitoring preferences.

To display the categories of traps along with a description of each one, do the following:

1. Click the **Traps** tab.
2. At the bottom of the Trap Information folder, click **Trap Filter**.



The following table lists all the traps and describes the conditions that trigger them when enabled. Traps that are enabled are recorded in the Trap Log.

Name	Trap Event
Generic Cold Start	The management card is reset.
Generic Warm Start	The occurrence of a software error that caused a spontaneous reset.
Generic Link Down	A port loses link. (The port is not specified.)
Generic Link Up	A port detects link. (The port is not specified.)
Generic Authentication Failure	Invalid SNMP community string is used.
Generic EGP Neighbor Loss	Not Applicable.

Name	Trap Event
Entity Configuration Change	A power supply or card is removed from or added to a chassis, or a chassis is removed from or added to a stack.
Entity Insert	A power supply or card is installed in a chassis, or a chassis is added to a stack.
Entity Remove	A power supply or card is removed from a chassis, or a chassis is removed from a stack.
Entity Reset	A chassis or card is reset.
Power Supply Status Change	Power supply status changes from ON to OFF or vice versa.
Ethernet Port Link Status Change	The presence of link on an Ethernet port is lost or detected.
SONET Port Link Status Change	The presence of link on a SONET port is lost or detected.
Sensor Threshold	The temperature or voltage exceeds the limits on a management card or access line card; or the fiber optic power level is exceeded on an access line card.
Redundant Switch Over	The active port changes from the primary to the secondary port on a redundant interface line card.
Remote Fault Alarm	A remote access line card's fiber port loses its receive link.
Ethernet Port Speed Change	The speed on an Ethernet port is changed.
TDM Port Link Status Change	The presence of link on a TDM port is lost or detected.
TDM Remote Fault Alarm	A remote TDM card's fiber port loses its receive link.
Enet Port Far End Fault Alarm	A remote x133-xx card's fiber port receiver fails to detect link.

### ***Filtering Traps***

1. From the Generic Traps or Enterprise Traps list, **check** or **uncheck** the boxes to include or exclude specific messages.
2. Click **Apply**.
3. When the confirmation message appears, click **OK**.
3. Click **OK** to return to the Trap Information folder.

**Tip:** When a dialog box offers both the **OK** and **Apply** buttons, click **OK** if you want the dialog box closed after applying any changes. Click **Apply** if you want to apply changes and keep the dialog box open.

## Managing Traps


Through NetBeacon, you can configure multiple management stations to monitor traps. If you are using another SNMP software application, such as WebBeacon, all of its trap managers are automatically added to NetBeacon's list of trap managers, along with the NetBeacon server. No trap managers are removed until you delete them.

### *Displaying the Trap Management Table*

To view which hosts are configured to receive trap notices, do the following:

1. Click the **Traps** tab.
2. Click **Trap Manager**.

The Trap Manager table appears.



The following table lists the Trap Manager information shown above, along with a brief description of each field.


Name	Description
IP Address	IP address of the workstation where trap notices are sent.
UDP Port	The User Datagram Protocol (UDP) port number.
Trap Manager Name	Name assigned to the trap manager.
Status	Indicates whether the manager is active or not in service. When active, traps are sent to the manager. When not in service, traps are logged but not sent.
SNMP Version	The SNMP version, either V1 or V2C.

### *Adding a New Trap Manager*

To add a new trap manager, do the following:

1. Click the **Traps** tab.
2. Click **Trap Manager**.
3. Click **Add**.

The Add Trap Manager Destination dialog box appears.



4. In the IP Address text box, type the *IP address* of the destination server or device to which traps will be sent.
5. In the UDP Port text box, type the trap manager's *UDP port number*. The default number is 9162. Port 162 is the standard SNMP trap port.
6. In the Name text box, type the *name* of the new trap manager.
7. Select **V1** or **V2C** from the drop-down list to set the SNMP version that will be used to send trap messages.
8. Select **Active** or **Not In Service** from the Status drop-down list. Traps are sent to the manager if you select Active. Traps are recorded but not sent if you choose Not In Service.

**Important:** Make sure your trap management workstations are configured to receive trap notices.

9. Click **OK**.
10. Click **Apply** or **OK** to update the trap destination table. Then click **OK** when the confirmation message appears.

### ***Reconfiguring a Trap Manager***


After you have configured your trap managers, you can change the name, SNMP version and status of a trap manager.

To edit trap management information, do the following:

1. Click the **Traps** tab.

2. Click **Trap Manager**.
3. In the table, click the trap manager you want to modify.
4. Click **Edit**.

The following Edit Trap Manager Destination dialog box appears.



5. In the Name text box, type the new *name* of the trap manager.
6. Select **V1** or **V2C** from the SNMP Version drop-down list.
7. Select **Active** or **Not In Service** from the Status drop-down list.
8. Click **OK**.
9. Click **OK** or **Apply** to update the trap destination table. Then click **OK** when the confirmation message appears.

### ***Deleting a Trap Manager***

To remove one or more trap managers, do the following:

1. Click the **Traps** tab.
2. Click **Trap Manager**.
3. In the table, click the row of the trap manager you want to remove.

**Tip:** To select more than one, press the CTRL key and select the other trap managers you want to remove.

4. Click **Delete**.
5. Click **OK** or **Apply**.
6. When the confirmation message appears, click **OK**.


## Sending E-mail Notifications

In addition to viewing messages, you can customize NetBeacon to send automatic e-mail notifications to one or more recipients when certain events occur.

### *Configuring E-mail Notifications*

To enable e-mail notifications for the currently selected device/stack, do the following:

1. Click the **Traps** tab.
2. Click **Trap E-mail Setup**.



3. In the SMTP e-mail server text box, type the *name* of the host e-mail server.
4. To send e-mail notifications, all devices including the currently selected device must be set to **Enabled**.


**Tip:** To prevent the selected device from sending e-mail notifications, select **Disabled** from the E-mail sending for current device drop-down list. All devices can be stopped from sending messages by selecting **Disabled** from the E-mail sending for all devices drop-down list.

5. From the Suppress repeated messages drop-down list, select **No** to allow all e-mails messages to be sent to the recipient(s). To restrict a message to be sent no more than once within a specified period, select the time interval from the list. For example, if you choose **15 minutes**, and the device records an Entity Reset trap twice within a 15-minute period, only one e-mail message will be sent to the e-mail recipient(s).
6. Click **Apply** or **OK**.
7. When the confirmation message appears, click **OK**.

Next, you create a list of recipients that you want to notify. You can enable/disable specific traps to individualize the list for each recipient.

8. To add a recipient to the notification list, click **Add** in the Trap E-mail Setup dialog box.


The Trap E-Mail - Add Notice dialog box appears.

The image shows a Windows-style dialog box titled "Trap E-mail - Add Notice". It has three text input fields at the top: "To", "From", and "Subject". Below these fields is a list of 20 checkboxes, each representing a different trap event. All checkboxes are currently checked. The events are: Generic Cold Start, Generic Warm Start, Generic Link Down, Generic Link Up, Generic Authentication Failure, Generic EGP Neighbor Loss, Entity Configuration Change, Entity Insert, Entity Remove, Entity Reset, Power Supply Status Change, Ethernet Port Link Status Change, Sonet Port Link Status Change, Sensor Threshold, Redundant Switch Over, Ethernet Remote Fault Alarm, Ethernet Port Speed Change, TDM Port Link Status Change, TDM Remote Fault Alarm, and Enet Port Far End Fault Alarm. At the bottom of the dialog are two buttons: "OK" and "Cancel".

9. In the To text box, type the *e-mail address* of the recipient. To specify multiple recipients, separate each recipient's e-mail address with a semicolon (;).
10. In the From text box, type the *e-mail address* of the person sending the message.
11. In the Subject text box, type a *description* of the notice. This information is optional.
12. Click **OK** to add the recipient to the notification list.
13. Repeat Steps 8-12 to add additional recipients.

Each e-mail notification is saved temporarily in the E-mail trap notices for the current device table. Its fields are described below.

Name	Description
To	E-mail address of the recipient of trap notices.
From	E-mail address of the sender of trap notices.
Subject	Description of the trap notice. (This field is optional and may be blank.)
Traps	Object identification numbers of the traps configured for the recipient.



14. Click **OK** or **Apply** to keep any changes made to the Trap E-Mail Setup.

15. Click **OK** when the confirmation message appears.

### Adding E-mail Notifications for Multiple Devices

NetBeacon only allows you to set up e-mail notices for one device or stack at a time. For each additional device or stack you want to configure, do the following:

1. Close the Trap E-mail Setup dialog box for the currently selected device.
2. Choose a new device from the Devices list in the lower left section of the NetBeacon window.
3. Repeat the steps in [Configuring E-mail Notifications](#).

### *Editing an E-mail Notice*

If you want to change any information for an existing e-mail notice recipient, do the following:

1. In the table under the Trap E-mail Setup dialog box, click on the notice you want to modify.
2. Click **View/Edit**.
3. Make the desired changes in the Trap E-mail - Edit Notice dialog box.
4. Click **OK**, then click **Apply** or **OK**.
5. Click **OK** when the confirmation message appears.




### ***Sending a Test E-mail Notice***

To send a generic test message to verify e-mail notification by the NetBeacon, do the following:

1. From the E-mail trap notices table, select the recipient of the test e-mail notice. You may select more than one recipient.
2. Click **Test**.
3. Click **OK** when the verification message appears.

The recipient will receive the following test e-mail message.



### ***Deleting an E-mail Notice Recipient***

To delete a recipient from the e-mail trap notices list, do the following:

1. From the E-mail trap notices table, select the recipient to delete.
2. Click Remove.
3. Click **Apply** or **OK**, then click **OK**.



## Chapter 5. Configuring Modules and Ports


Through NetBeacon, you can monitor and configure all the modules<sup>1</sup> and ports on your device. In addition to overriding hardware switch settings, you can enable advanced functions such as Switch On No Activity Received (SONAR) on the redundant interface line card and Far End Fault on the T1/E1 card. You can also obtain complete Ethernet and RMON port statistics on the access line cards.

### Displaying Module Information

The Module Information folder displays information about the modules (e.g., the management card and the access line card) installed in the selected device. If the device is part of a stack, all modules in the entire stack are included.

Information includes the location, name, asset ID, type, and a brief description of the module, along with its operating status, uptime, version, date of manufacture, and part number.

1. Click the **Modules** tab to display the Module Information folder.



Location	Name	Description	Type	Up Time
Chassis 1, Slot 4	Module1_4	100M TX to FX MM/SC	Single Interface Line Card	13 days 18h:32...
Chassis 1, Slot 5	Module1_5	100M TX to FX MM/SC	Single Interface Line Card	13 days 18h:32...
Chassis 1, Slot 7	Module1_7	10M TP to FL MM/ST	Single Interface Line Card	13 days 18h:32...
Chassis 1, Slot 8	Module1_8	100M TX to FX MM/ST	Single Interface Line Card	13 days 18h:32...
Chassis 1, Slot 9	Module1_9	100M TX to FX MM/ST	Single Interface Line Card	13 days 18h:32...
Chassis 1, Slot 10	Module1_10	10M TP to FL MM/ST	Single Interface Line Card	13 days 18h:32...
Chassis 1, Slot 11	Module1_11	100M TX to FX MM/ST	Single Interface Line Card	13 days 18h:32...
Chassis 1, Slot 12	Module1_12	10M TP to FL MM/ST	Single Interface Line Card	13 days 18h:32...
Chassis 1, Slot 13	Module1_13	100M TX to FX MM/ST	Single Interface Line Card	13 days 18h:32...
Chassis 1, Slot 14/15	Module1_15	100M TX to Dual FX MM/SC	Redundant Interface Line Card	13 days 18h:32...
Chassis 1, Slot 17	Module1_17	10M Dual TP Management	Management	13 days 18h:32...
Chassis 2, Slot 1	Module2_1	1000M SX MM/SC to LX SM/SC	Gigabit Interface Line Card	13 days 18h:33...
Chassis 2, Slot 2	Module2_2	10/100M TX to 10/100M TX	Auto Interface Line Card	13 days 18h:33...
Chassis 2, Slot 3	Module2_3	100M TX to FX MM/SC	Single Interface Line Card	13 days 18h:33...
Chassis 2, Slot 8	Module2_8	100M TX to FX MM/ST S/P	Access Line Card	13 days 18h:33...
Chassis 2, Slot 8, Port 2, Remote 1	Module2_8_2_1	100M TX to FX MM/ST S/P	Access Line Card	13 days 18h:33...
Chassis 2, Slot 13/14	Module2_14	100M TX to Redundant FX(SM ST)	Redundant Interface Line Card	13 days 18h:33...
Chassis 2, Slot 17	Module2_17	Management Module Single Port	Management	13 days 18h:33...

**Tip:** Clicking a module in the chassis view also displays the Module Information folder. The selected module is highlighted.

The following table lists the Module Information shown in this folder, along with a brief description of each field.

<sup>1</sup> Line cards are called modules in NetBeacon.


Name	Description
Location	The chassis and slot where the module is installed.
Name	The user-assigned or default name for the module.
Description	Details on the module's specifications.
Type	The type of module – a management card, an access line card, a single interface line card, etc.
Up Time	The length of time the module has been in operation since startup. For version 1.3 or older modules, this field is not supported and will be displayed as Unknown.
Oper Status	Operational status of the module, either Enabled (active) or Disabled (inactive).
Asset ID	User-defined asset tracking identifier.
Version	The version number or letter of the module.
Manufacture Date	Date the module was manufactured.
Part Number	The part number assigned to the module for identification purposes.

2. To reset one or more modules, do the following:

- Select one or more modules from the table by clicking on it. Hold down the CTRL key while clicking to select multiple modules.
- Click **Reset Modules**.
- When the confirmation messages appear, click **Yes**, then click **OK**.

3. Click **Refresh** to display the current information configured for the modules.

4. To view information for a specific type of module, select it from the drop-down menu, which displays all the types of modules installed in the chassis or stack.



In addition to the location, name, type, operating status, and number of ports, the information shown for each module type includes functional settings that are unique to it. The table below describes these settings.

Name	Description
<b>Auto Interface Line Card</b>	
Backpressure	Status of the backpressure function, which forces a collision on a port when it cannot accommodate incoming data. See <a href="#">Configuring the 10/100Mbps Line Card</a> .
FD Flow Control	If FD Flow Control is enabled, the card will issue a PAUSE frame when there is no buffer space available for incoming packets. See <a href="#">Configuring the 10/100Mbps Line Card</a> .
Auto Recovery	Auto-Recovery allows the card to restart its fiber connection after a link loss event. See <a href="#">Configuring the 10/100Mbps Line Card</a> .
<b>Single Interface Line Card, Access Line Card, Redundant Interface Line Card, Auto Interface Line Card</b>	
LLCF (Link Loss Carry Forward)	When LLCF is enabled, if one port loses link, the module will not transmit a link pulse from the other port.
<b>Single Interface Line Card</b>	
LLCF/CLCF (Copper Loss Carry Forward)	CLCF only applies to TX-FX gigabit cards. When CLCF is enabled, the fiber port's transmitter shuts down if the copper port stops receiving link pulses. <sup>2</sup>
<b>Redundant Interface Line Card<sup>3</sup></b>	
Mode Control	The mode control is either Dynamic Recovery or Select A/B.
Active Port	The active port is either Primary or Secondary.
Auto Restore Primary Circuit	When enabled, the module reverts the active port back to the Primary port when the primary link is reestablished.
Link Pulse Control	Link signals are sent out both the Primary and Secondary ports when Link Pulse Control (LPC) is enabled. Link signals are sent out only on the active port if LPC is disabled.
Redundant Transmission	When enabled, transmits data on both the Primary and Secondary ports (LPC must be enabled). When disabled, transmits data on the active port only.

<sup>2</sup> See the *Radiance Gigabit Single Interface Line Cards ~ Installation and User Guide*, "Copper Loss Carry Forward (CLCF)," for additional information.

<sup>3</sup> See the *Radiance 10Mbps or 100Mbps or 1000Mbps Redundant Interface Line Cards ~ Installation and User Guide* or the "redundant twister" *Installation and User Guide*, Step 2 "Set the DIP Switches," for details regarding the card's switch settings.

Name	Description
Secondary Switch Occurred	Indicates whether or not the active port has changed.
Select A/B	Only applicable in Select A/B Mode. Select A enables the Primary port. Select B enables the Secondary port.
SONAR (Switch On No Activity Received)	Not applicable to all redundant interface line cards. When enabled, the module automatically changes its active port if the active port receives no data for at least 2 seconds and data activity is detected on the backup port.

### ***Changing a Module Name and Asset ID***

1. Open the Module Configuration dialog box by doing one of the following:

- From the table in the Modules folder, double-click the row containing the module to rename.
- Right-click the module in the chassis view and select **Module Configuration** from the pop-up menu.
- Double-click the image of the module's thumbscrew in the chassis view.

The Module Configuration dialog box displays the current information relating to the module you selected. The information displayed in the top half of the dialog box relates to the module and the information displayed in the bottom half relates to the converters on the module.

2. In the Name text box, type the *name*<sup>4</sup> you want to assign to the module.

3. In the Asset ID text box, type the *asset tracking identifier*<sup>5</sup> you want to assign to the module.

4. Click **Apply**, then click **OK**.

---

<sup>4</sup> There is a limit of 32 characters for the module name. Do not use the following characters: . ; & = : " < > .

<sup>5</sup> There is a limit of 32 characters for the asset ID. Do not use the following characters: . ; & = : " < > .

System: 192.168.3.163

Selected Module Information

Name	Module1	Manufacture Date	05/09/2002
Type	Single Interface Line Card	Hardware Revision	A
Description	10M TP to BNC	Diagnostic Test Status	Good
Part Number	R111-12	Oper Status	Enabled
Serial Number	A991200572	Asset ID	

Converters on this module: (1)

Location	Name	Oper Status	Ports	Type	LLCF/CLCF
Chassis 1, Slot 1	Module1	Enabled	2	Single Interface Line Card	N/A

OK Apply Cancel Reset Module Reset To Default

The following table describes the fields shown in the top half of the Selected Module Information section of the Module Configuration dialog box.

Name	Description
Name	Default or user-defined name of the module.
Type	The type of module installed in the slot – a management card, an auto interface line card, a gigabit interface line card, an OC-3 interface line card, an OC-12 interface line card, an access line card, a single interface line card, a TDM card, or a redundant interface line card.
Description	Details on the module’s specifications.
Part Number	The part number assigned to the module for identification purposes.
Serial Number	The serial number assigned to the module for identification purposes.
Manufacture Date	The date the module was manufactured.
Hardware Revision Number	The version number of the module.
Diagnostic Test Status	The results of the diagnostics test of the module.
Oper Status	Operational status of the module, either Enabled or Disabled.
Asset ID	User-defined asset tracking identifier.


The bottom half of the dialog box provides information relating to the module’s media converter(s). Refer to Displaying Converter Information for details about these fields.

## Displaying Management Module Information

The management card is located in slot 12 of a 12-slot chassis, slot 17 of a 17-slot chassis, or either slot of a two-slot chassis.

To display management card details, do the following:

1. Double-click the management card row from the Module Information folder.



Module Configuration - Chassis 1, Slot 1

System: 192.168.3.163

Selected Module Information

Name	Module1	Manufacture Date	05/09/2002
Type	Single Interface Line Card	Hardware Revision	A
Description	10M TP to BNC	Diagnostic Test Status	Good
Part Number	R111-12	Oper Status	Enabled
Serial Number	A991200572	Asset ID	

Converters on this module: (1)

Location	Name	Oper Status	Ports	Type	LLCF/CLCF
Chassis 1, Slot 1	Module1	Enabled	2	Single Interface Line Card	N/A


OK Apply Cancel Reset Module Reset To Default

**Tip:** Double-clicking the management module in the chassis view also displays this dialog box.

The bottom half of the dialog box provides detailed information about the management card's Ethernet port(s).

2. Click the **Advanced** button.

The Management Module Details dialog box appears.



Management Module Details - Chassis 1, Slot 17

System: 192.168.3.170

Image Information

Image	Name	Version
Application		
Boot	boot bin	3.4.0.Baseline...
Core	corpm blz	3.4.0.Baseline...

Memory Information

RAM Memory Size: 32768 KB

Flash Memory Size: 8192 KB

NVRAM Memory Size: 8 KB

Embedded Servers

Telnet Server: Enabled

FTP Server: Enabled

HTTP Server: Enabled

HTTP Redirect: Local

HTTP Redirect URI: http://

BootP Server: Disabled

OK Apply Cancel




Name	Description
<b>Image Information</b>	
Image	Software image type.
Name	File name of the software image.
Version	Version number of the software image.
<b>Memory Information</b>	
RAM Memory Size	The amount of volatile RAM memory on the card.
Flash Memory Size	The amount of non-volatile flash memory on the card.
NVRAM Memory Size	The amount of non-volatile memory on the card. This memory is backed up by battery.
<b>Embedded Servers</b>	
Telnet Server	Enable or disable the Telnet server.
FTP Server	Enable or disable the FTP server.
HTTP Server	Enable or disable the Web server.
HTTP Redirect	Set the Web server so it points to the local device (Local) or redirect it to another IP address or URL (Redirected).
HTTP Redirection URL	The IP address or URL where the Web server will go to if the Web server is redirected away from the local device.
BootP Server	Enable or disable the BootP server. This field is only applicable to the R502-M management module.

### ***Displaying a Remote Access Line Card or Access ONU Information***

A remote access line card or access optical network unit (ONU) appears below the card it is connected to in the chassis view, if Show Remotes is enabled in the View menu. To see a larger image of the remote card or ONU, double-click on the image of the remote card/ONU. The module information and a larger view of the line card or ONU appear in the dialog box.

**Module Configuration - Chassis 1, Slot 13, Port 2, Remote 1**

System: 192.168.3.163



**Selected Module Information**

<b>Name</b>	Module13_2_1	<b>Manufacture Date</b>	04/29/2003
<b>Type</b>	Access Line Card	<b>Hardware Revision</b>	2
<b>Description</b>	10/100 TX to FX SM/SC S/M	<b>Diagnostic Test Status</b>	Good
<b>Part Number</b>	RA21-14	<b>Oper Status</b>	Enabled
<b>Serial Number</b>	B031700352	<b>Asset ID</b>	
<b>PIC Revision</b>	0	<b>FPGA Revision</b>	1

**Converters on this module: (1)**

Location	Name	Oper Status	Ports
Chassis 1, Slot 13, Port 2, Remote 1	Module13_2_1	Enabled	2

OK Apply Cancel Reset Module Reset To Default Advanced...

In addition to the standard information provided in the Selected Module Information section, two additional fields are shown for an access product.

Name	Description
PIC Revision	Primary Interexchange Carrier revision number
FPGA Revision	Field-Programmable Gate Array revision number

## Configuring a Converter

The bottom half of the Module Configuration dialog box contains information regarding the media converters on the selected module.

The information includes the location of the converter, its name, operational status, number of ports, type, and whether the Link Loss Carry Forward (LLCF) or Copper Loss Carry Forward (CLCF) function is enabled, disabled or not applicable.

Converters on this module: (1)						
Location	Name	Oper Status	Ports	Type	LLCF/CLCF	
Chassis 1, Slot 11	Module11	Enabled	2	Single Interface Line Card	Disabled	

The following table lists the converter information, along with a brief description of each field.

Name	Description
Location	The chassis number in the stack, and the slot or converter number in the chassis.
Name	The user-assigned or default name of the converter.
Oper Status	Operational status of the media converter, either Enabled (active) or Disabled (inactive).
Ports	The number of ports on the converter.
Type	The type of media converter (e.g., an access line card, a single interface line card, or a TDM T3 card).
LLCF/CLCF	<p>When LLCF is enabled, if one port loses its link, the converter will not transmit a link pulse from the other port.</p> <p>CLCF is only applicable to the 1000Mbps TX-FX line cards. When CLCF is enabled, the fiber port's transmitter shuts down if the copper port stops receiving link pulses.</p>

### ***Displaying Converter Information***

Another way to view converter information is to open the Converter Configuration dialog box using one of the following methods:


- From the Module Configuration dialog box shown above, double-click the row containing the converter.
- Double-click the module in the chassis view.
- Right-click the module in the chassis view and select **Converter Configuration** from the pop-up menu.

The Converter Configuration dialog box displays the current information relating to the converter you selected. The information displayed in the top half of the dialog box relates to the converter.

The bottom half of the dialog box displays detailed information about each of the ports on the converter. Refer to Displaying Port Details for descriptions of the Port fields shown.

### ***Assigning a Converter Name***

1. Open the Converter Configuration dialog box using one of methods described in Displaying Converter Information.
2. In the Name text box, type the *name* you want to assign to the converter.




3. Click **Apply**, then click **OK**.

### *Applying Link Loss Carry Forward*

In addition to changing the name, you can enable or disable Link Loss Carry Forward (LLCF) on the modules that have this function.

When LLCF is enabled, if one port loses its link, the converter will not transmit a link pulse from the other port.

1. Open the Converter Configuration dialog box using one of methods described in Displaying Converter Information.
2. From the Link Loss Carry Forward drop-down list, select **Enabled** or **Disabled**.




3. Click **Apply**, then click **OK**.

## Applying Copper Loss Carry Forward

Copper Loss Carry Forward (CLCF) is only applicable to the 1000Mbps TX-FX line cards. CLCF is disabled by default.

When CLCF is enabled, the fiber port's transmitter shuts down if the copper port stops receiving link pulses. To apply CLCF, do the following:

1. Open the Converter Configuration dialog box for the line card to configure.
2. From the Copper Loss Carry Forward drop-down list, select **Enabled**.
3. Click **Apply**, then click **OK**.



## Configuring the Redundant Interface Line Card

To configure a redundant interface line card, do the following:

1. In the chassis view, double-click the module to configure.


The Converter Configuration dialog box for a redundant line card appears.

2. Click **Advanced**.

The Redundant Interface Line Card Details dialog box displays the Mode and Mode Control settings for the selected module and active port. You can override the DIP switches on the board by changing these settings.

3. Select the Mode option: **Dynamic Recovery Mode (DRM)** or **Select A/B**.

## Dynamic Recovery Mode



When Dynamic Recovery Mode is active, both links are directed to the same network. Only the primary link is active unless a failure occurs, in which case the secondary link assumes primary control, or redundant transmission mode is enabled.

If you select the auto restore option, then the primary link is reactivated as soon as it is restored. Otherwise, the secondary port remains active if its link does not fail.

Use DRM when you want to ensure continuous network connectivity and secure uninterrupted user access in the event of a link failure.

Dynamic Recovery Mode:	Auto Restore Primary Circuit: <ul style="list-style-type: none"><li>• Enable – reverts the active port back to the primary port when the primary link is reestablished.</li><li>• Disable – keeps the secondary port as the active port even if the primary link is reestablished.</li></ul>
	Link Pulse Control (LPC): <ul style="list-style-type: none"><li>• Enable – sends an idle signal on both the primary and secondary ports.</li><li>• Disable – sends an idle signal on only the active port.</li></ul>
	Redundant Transmission: <ul style="list-style-type: none"><li>• Enable – sends data on both the primary and secondary ports simultaneously.</li><li>• Disable – sends data on the active port only.</li></ul>


**Tip:** You must enable LPC to enable redundant transmission mode.

## Applying SONAR


For redundant interface line cards with Switch On No Activity Received (SONAR), an additional parameter appears in the top half of the Redundant Interface Line Card Details dialog box. SONAR affects the module's response to a loss of activity (LOA) for two seconds on the active port. SONAR is applicable only in Dynamic Recovery Mode with Link Pulse Control enabled.

The other switch settings do not affect SONAR operation. However, SONAR will override the Auto Restore Primary Circuit switch. If both these switches are enabled, the active port will not automatically revert back to the primary port (after switching to the secondary port) if the primary port has link but no data activity. Data activity on the primary port must also be detected during the two-second time-out period before the active port reverts back to the primary port.

To enable SONAR, do the following:




1. In the Redundant Interface Line Card Details dialog box, choose **Enabled** from the SONAR drop-down list.
2. Set the Mode to **Dynamic Recovery Mode**.
3. Make sure that Link Pulse Control is **Enabled**.
4. For a Gigabit redundant card, the loss of activity (LOA) period can be set anywhere from 1 to 31 seconds. Slide the pointer to select the desired number of seconds. If the active port remains idle for the specified time, the redundant interface will verify activity on the secondary port, and switch to that port once traffic is detected.



5. Click **Apply**.
6. A message appears stating that the operation was successful. Click **OK**.

#### Select A/B Mode

When Select A/B is active, each link on the redundant interface line card operates independently and is directed to a different network. Only one link (primary or secondary) is active at a time.



Use this mode to redirect traffic from one network to another, in less critical points in the network where full redundancy is not required.

Select A/B: Select A – Enables the primary port.  
Select B – Enables the secondary port.

Do one of the following:

- Click **Apply** to confirm your changes.
- Click **Cancel** to discard your changes and return to the Converter Configuration dialog box.
- Click **OK** to return to the Converter Configuration dialog box.

### *Configuring the 10/100Mbps Line Card*

The 10/100Mbps Auto Interface Line Card (AutoTwister) is a rate adapter that connects 10Mbps devices to 100Mbps devices, copper-based networks to fiber-based networks, and full-duplex systems to half-duplex systems. Depending on your model, various features are available for this card.

To configure a 10/100Mbps line card, do the following:

- In the chassis view, right-click the module to configure and select **Converter Configuration** from the pop-up menu.

The Converter Configuration dialog box for a 10/100Mbps line card appears.

### **Link Loss Carry Forward and Full-Duplex Flow Control**

1. For a 10/100Mbps line card with LLCF functionality, you can select **Enabled** or **Disabled** from the drop-down list, and then click **Apply**. The default is LLCF disabled.




2. On some models, an additional feature called Full-Duplex (FD) Flow Control is provided. If you enable FD Flow Control, the 10/100Mbps line card will issue a PAUSE frame when there is no buffer space available for incoming packets. Select **Enabled** or **Disabled** from the drop-down list, and then click **Apply**. This setting is enabled by default.

#### Backpressure (Half-Duplex Flow Control)

1. At the bottom of the Converter Configuration dialog box, click **Advanced**.

The Backpressure dialog box appears. Here you can change the card's backpressure setting. The default setting is disabled.



Backpressure can be enabled only on ports operating at half duplex. When backpressure is activated, the 10/100Mbps card generates a jamming pattern to force a collision on a port when the converter cannot allocate a buffer for the port's incoming packets. Activating backpressure enables it on both ports of the card. Backpressure is ignored in full duplex because collisions are not generated in this mode.

2. Select **Disabled** or **Enabled**.
3. Do one of the following:
  - Click **Apply** and then **OK** to confirm your change.
  - Click **Cancel** to discard your change and return to the Converter Configuration dialog box.
  - Click **OK** and then **OK** to confirm any changes and return to the Converter Configuration dialog box.

#### Auto-Recovery

The x643-xx 10/100Mbps line cards include the Auto-Recovery feature to assist in troubleshooting remote connections. Auto-Recovery allows the card to restart its fiber connection after a link loss event.

Auto-Recovery is enabled only when all of the following conditions are met:


- Auto-Recovery is enabled.

- Link Loss Carry Forward is enabled.
- Link Loss Return is enabled.
- Auto-Negotiation is disabled.

Through NetBeacon, you can easily configure the settings to automatically enable Auto-Recovery by doing the following:

1. In the Converter Configuration dialog box, click **Related Settings**. (If all the conditions necessary for Auto-Recovery are already set correctly, this button will be dimmed.)

The Engaging the Auto-Recovery Circuit dialog box appears. It lists the current status of the four settings upon which Auto-Recovery depends.



2. Click **Change all settings needed to engage Auto-Recovery** to make all the required changes in one simple step.
3. Click **OK**. When you return to the Converter Configuration dialog box, the Related Settings is now unavailable.


### *Managing the Chassis Stacking Line Card*

The Chassis Stacking Line Card is a 10/100Mbps four-port TX switch that can be used to stack up to four Metroblity chassis. The Module Configuration dialog box for the card provides the standard module information, with one addition—the Complex Programmable Logic Device (CPLD) revision number.

To configure a chassis stacking line card, do the following:

- In the chassis view, right-click the module to configure and select **Converter Configuration** from the pop-up menu.

The Converter Configuration dialog box for a chassis stacking line card appears. There are three settings you can modify through this window.



### Port Duplex, and Full and Half Duplex Flow Control

3. The Port Duplex setting determines the duplex mode on all ports that have auto-negotiation disabled. The ports will operate at full duplex if Port Duplex is enabled. The ports will operate at half duplex if the setting is disabled. Select **Enabled** or **Disabled** from the drop-down list.

If auto-negotiation is enabled on a port, that port will ignore the Port Duplex switch setting. The duplex mode will be determined through the auto-negotiation process.

4. Full-Duplex (FD) Flow Control is provided as a means of avoiding packet loss during times of network congestion. This setting can only be changed through software control and is enabled by default. With FD Flow Control enabled, the chassis stacking line card will issue a PAUSE frame if there is no buffer space available for incoming packets. Select **Enabled** or **Disabled** from the drop-down list.

4. A

Backpressure can be enabled only on ports operating at half duplex. When backpressure is activated, the 10/100Mbps card generates a jamming pattern to force a collision on a port when the converter cannot allocate a buffer for the port's incoming packets. Activating backpressure enables it on both ports of the card. Backpressure is ignored in full duplex because collisions are not generated in this mode.

5. Select **Disabled** or **Enabled**.
6. Do one of the following:
  - Click **Apply** and then **OK** to confirm your change.
  - Click **Cancel** to discard your change and return to the Converter Configuration dialog box.
  - Click **OK** and then **OK** to confirm any changes and return to the Converter Configuration dialog box.

## Displaying Access Line Card Details


The access line card contains three internal voltage regulators and a temperature sensor.

To view information about the card's regulators and sensor, do the following:

From the Module Information folder, double-click the row containing an access line card.

The Module Configuration dialog box appears.

1. Click **Advanced**.




The table below describes the color coding used on the gauges.

Color	Description
Green	Normal operating range.
Yellow	Warning: above or below the recommended operating range.
Blue	Danger: voltage/temperature is too low.
Red	Danger: voltage/temperature is too high.

2. Click **Temperature History** or **Voltage History** to view a graphical display of either the card's temperature or regulated voltages over an extended period of time. (This feature requires the database plugin on your NetBeacon server.)

**Tip:** Double-clicking on any of the gauges also displays the graphs.




3. To change the maximum length of time shown in the graph, select one of the options from the Time Span drop-down menu.

### *Applying Write-Protection*

By default, the access line cards are not write-protected. To prevent a remote access line card from making changes to the locally managed card, do the following:

1. Select **Read Only** from the Remote Write Protect drop-down list in the Access Line Card Module Details dialog box.



2. Click **Apply**, then click **OK**.

## **Configuring the Ports**

The Ports folder displays information about the ports on the selected device. If the device is part of a stack, the ports on the other chassis in that stack are also displayed. In addition to the port information, the Ports folder provides an option to display the Ethernet interface statistics on the management card(s). If the chassis or stack includes an access line card, an option to view RMON statistics appears. If a T1/E1 card is installed, an option to view TDM information appears.

### *Displaying Port Details*

Click the **Ports** tab to display the Port Information folder. Make sure **Port Information** is selected from the drop-down menu. The information in this table is for display purposes only and cannot be changed.

**Tip:** Clicking a port in the chassis view also opens the Ports folder. (The port you clicked is highlighted.)

Location	Name	Type	Speed	Oper Status	Duplex	Auto Negotiation	Link Status	Link Loss Ret
Chassis 1, Slot 1, Port 1	Port1_1	T1	N/A	Enabled	N/A	N/A	No Link	N/A
Chassis 1, Slot 1, Port 2	Port1_2	T1-F-MM	N/A	Enabled	N/A	N/A	No Link	N/A
Chassis 1, Slot 2, Port 1	Port2_1	T1	N/A	Enabled	N/A	N/A	No Link	N/A
Chassis 1, Slot 2, Port 2	Port2_2	T1-F-MM	N/A	Enabled	N/A	N/A	No Link	N/A
Chassis 1, Slot 3, Port 1	Port3_1	E3	N/A	Enabled	N/A	N/A	No Link	N/A
Chassis 1, Slot 3, Port 2	Port3_2	E3-F-MM	N/A	Enabled	N/A	N/A	Link Detected	N/A
Chassis 1, Slot 4, Port 1	Port4_1	E3	N/A	Enabled	N/A	N/A	Link Detected	N/A
Chassis 1, Slot 4, Port 2	Port4_2	E3-F-MM	N/A	Enabled	N/A	N/A	Link Detected	N/A
Chassis 1, Slot 5, Port 1	Port5_1	100Base-TX	100	Enabled	Full	N/A	Link Detected	N/A
Chassis 1, Slot 5, Port 2	Port5_2	100Base-FX OM 300	100	Enabled	Full	N/A	No Link	N/A

The following table lists the information shown in the Ports folder, along with a brief description of each field.

Name	Description
Location	Chassis number in the stack, slot in the chassis, and port on the card. For a remote access line card, the remote card and port numbers are also included.
Name	Name assigned to the port.
Type	The port's media type.
Speed	Speed in megabits per second (Mbps).
Oper Status	Operational status of the port, either Enabled or Disabled.
Duplex	Duplex mode of the port, (Full, Half, or N/A).
Auto Negotiation	Auto-negotiation status on the port (Enabled, Disabled, or N/A).
Link Status	Indicates whether or not link is detected.
Link Loss Return	Link Loss Return status on the port (Enabled, Disabled, or N/A).
Cross Over	Indicates whether a copper port's MDI-X/MDI-II switch is set to Parallel or Crossed Over. Not applicable to fiber ports.

## Displaying Management Module Statistics

To view the Ethernet port statistics for the management cards installed in each chassis of the selected stack, do the following:

1. Select **Interface Statistics** from the drop-down menu in the Ports folder.

Information | Configuration | Stack | Traps | Modules | Ports

System: 192.132.35.170

Interface Statistics

Interface Statistics (Total)

Location	IfIndex	In Octets	Out Octets	In Errors	Out Errors	In Discards	Out Discards
Chassis 1, Slot 17, Port 1	1	467,323	724,503	4	0	0	0
Chassis 1, Slot 17, Port 2	2	2,826,584	1,685,936	0	0	0	0
Chassis 2, Slot 17, Port 1	5	78,152,174	65,821,762	0	0	0	0
Chassis 3, Slot 2, Port 1	6	59,682,044	47,244,822	0	0	0	0
Chassis 4, Slot 2, Port 1	4	59,814,314	47,477,973	0	0	0	0

Interface Count: 5

Refresh

Clear Counters

Show Deltas

Print...

The following table lists and describes the Interface Statistics fields.

Name	Description
Location	The chassis, slot and port numbers of the management card.
IfIndex	The interface index number.
In Octets	Number of bytes received.
Out Octets	Number of bytes transmitted.
In Errors	Number of inbound packets with errors.
Out Errors	Number of outbound packets with errors.
In Discards	Number of inbound packets discarded with no errors.
Out Discards	Number of outbound packets discarded with no errors.

2. Click **Clear Counters** to reset all the counters to 0.
3. Click **Show Deltas** to display the difference between the totals shown on the screen and the totals when you click the button.
4. Click **Refresh** to update the statistics.
5. Click **Print** to obtain a printout of the Interface Statistics table.

### Displaying RMON Statistics

To view the complete Remote Monitoring (RMON) Group I Ethernet Statistics for the access line cards, select **RMON+ Statistics** from the drop-down menu in the Ports folder. Scroll to the right to view all the information.

Information	Configuration	Stack	Traps	Modules	Ports
System: 192.132.35.170					RMON+ Statistics
RMON+ Statistics (Total)					
Location	RMON Index	Octets	Packets	Receive Blocked ...	Receive Block
Chassis 2, Slot 8, Port 1	18496	0	0	0	
Chassis 2, Slot 8, Port 2	18560	698,240,112	882,840	0	
Chassis 2, Slot 8, Port 2, Remote 1, Port 1	18565	698,353,056	882,946	0	
Chassis 2, Slot 8, Port 2, Remote 1, Port 2	18566	0	0	0	
RMON Interface Count: 6					
<input type="button" value="Refresh"/> <input type="button" value="Clear Counters"/> <input type="button" value="Show Deltas"/> <input type="button" value="Print..."/>					

## Viewing TDM Information

If you have any TDM cards installed in your chassis/stack, select **TDM Information** from the Ports folder drop-down menu. Scroll to the right to view all the information.

Information | Configuration | Stack | Traps | Modules | Ports

System: 192.132.35.222

TDM Information

Location	Name	Type	Oper Status	Link Status	Line Status	AIS Status	Local Loopback	TX Line Code	Bipolar
Chassis 1, Slot 3, Port 1	Port3_1	T3	Enabled	Link Detected	Active	N/A	Disabled	N/A	N/A
Chassis 1, Slot 3, Port 2	Port3_2	T3-F-MM	Enabled	Link Detected	Active	N/A	Disabled	N/A	N/A
Chassis 1, Slot 6, Port 1	Port6_1	T3	Enabled	No Link	Inactive	N/A	Disabled	N/A	N/A
Chassis 1, Slot 6, Port 2	Port6_2	T3-F-MM	Enabled	No Link	Inactive	N/A	Disabled	N/A	N/A
Chassis 1, Slot 9, Port 1	Port9_1	T3	Enabled	Link Detected	Active	N/A	Disabled	N/A	N/A
Chassis 1, Slot 9, Port 2	Port9_2	T3-F-SM	Enabled	Link Detected	Active	N/A	Disabled	N/A	N/A

Port Count: 6

Refresh

Print...


## Changing the Port Name

You can view additional port information from the Ports Configuration dialog box. For cards such as the redundant interface line card, the only information you can change is the port name.

- Open the Port Configuration dialog box by doing one of the following:
  - From the **Ports** tab, select a port by double-clicking it.
  - Double-click the port in the chassis view.

The Port Configuration dialog box appears.





2. In the Name text box, type the *name*<sup>6</sup> to assign to the port.
3. Click **Apply**.
4. When the confirmation message appears, click **OK**.
5. Click **OK** to return to the Ports folder.


### *Applying Link Loss Return*

In addition to the name, you can enable or disable Link Loss Return<sup>7</sup> (LLR) on any fiber port with this feature. LLR works in conjunction with Link Loss Carry Forward (LLCF). When a lost link signal is returned to an unmanaged card, that lost link must then be carried forward to a managed device for trap generation.

When LLR is enabled, the port's transmitter shuts down if its receiver fails to detect a valid receive link. LLR should only be enabled on one end of a link and is typically enabled on the unmanaged or remote device.

To apply LLR, do the following:

1. In either the chassis view or the Ports folder, double-click the port to configure.



<sup>6</sup> There is a limit of 32 characters for the port name. Do not use the following characters: . ; & = : " < > .

<sup>7</sup> For additional information, refer to "Link Loss Return" in the user guide for the card you are configuring.


2. Choose **Enabled** from the Link Loss Return drop-down list.
3. Click **Apply**. When the message appears, click **OK**.

### *Configuring the 10/100Mbps Ports*

Depending on the type of 10/100Mbps auto interface line card (AutoTwister) installed, there are two or three port settings that can be configured through NetBeacon. These include auto-negotiation, duplex, speed, and Link Loss Return. The duplex mode can be changed on any 10/100Mbps port. For a copper port, speed and auto-negotiation can also be changed. For a fiber port, Link Loss Return can be enabled or disabled.

To configure the 10/100Mbps ports, do the following:

1. Double-click the port to configure in either the chassis view or the Ports folder.
2. The Port Configuration dialog box appears. The dialog box for a copper port is shown on the left. The dialog box for a fiber port is shown on the right.



Select the port settings from the drop-down lists.

For a copper port, do any of the following:

- Set Speed to **10Mbps** or **100Mbps**.
- Set Duplex Mode to **Half** or **Full**.
- Set Auto-Negotiation to **Disabled** or **Enabled**.

For a fiber port, do any of the following:

- Set Duplex Mode to **Half** or **Full**.
- Set Link Loss Return to **Disabled** or **Enabled**.

Changing these settings will override the DIP switches<sup>8</sup> on the 10/100Mbps line card.

---

<sup>8</sup> Refer to the *Intelligent 7500 10/100 AutoTwister Module Installation and User Guide* or the *Radiance 10/100Mbps Interface Line Cards Installation and User Guide*, Step 2 "Set the Switches," for additional information.


3. Click **Apply**, and then click **OK**.

### *Configuring the R133 Ports*

The 100Mbps TX-FX R133 ports include additional functions that are not available on other single interface line cards. These functions include Far End Fault notification, auto-negotiation, duplex selection, and remote loopback testing.

To configure the R133 ports, do the following:

1. Double-click the port to configure in either the chassis view or the Ports folder.
2. The Port Configuration dialog box appears. The dialog box for a copper port is shown on the left. The dialog box for a fiber port is on the right.



Select the port settings from the drop-down lists.

For a copper port, do any of the following:

- Set Duplex Mode to **Half** or **Full**.
- Set Auto-Negotiation to **Disabled** or **Enabled**.

If auto-negotiation is disabled, the duplex setting will determine the mode at which the port operates. When auto-negotiation is enabled, the copper port will advertise full duplex capability if the duplex mode is set to full. The copper port will advertise half duplex capability if the duplex mode is set to half.

For a fiber port, do any of the following:

- Set Remote Loopback to **Disabled** or **Enabled**. During remote loopback, the R133 card generates a test pattern that is sent to the remote unit, which then returns the test pattern back to the R133 card. The card reads the returned data and verifies proper transmission. To run the remote fiber loopback test, set Remote Loopback to Enabled and make sure the Loopback Response setting on the remote unit is also enabled. (If the remote unit is a 100Mbps Delta Class "twister", be sure that its DSLB DIP switch is OFF.)

- Set Loopback Response to **Disabled** or **Enabled**. This setting determines the response of the fiber port to requests to enter remote loopback. If the setting is disabled, the port will ignore all remote loopback requests. If the setting is enabled, the port will permit remote loopback to occur. That is, it will return the test data back to the sending device.
- Set Far End Fault (FEF) to **Disabled** or **Enabled**. When FEF is enabled, the loss of inbound link pulses on the port generates an alarm which is sent out the port's transmitter. FEF also enables the port to read the FEF alarm. To function properly, the FEF setting must be the same on both the local and remote x133 line cards.

Changing these settings will override the DIP switches<sup>9</sup> on the x133 line card.

3. Click **Apply**, and then click **OK**.


### *Configuring the Access Line Card Ports*

Through NetBeacon, you can override the hardware switches on the access line card and modify its internal default settings. You also can view its RMON port statistics and data history as graphs.

To change the settings on an access line card, do the following:

1. Double-click the port to configure in either the chassis view or the Ports folder.

The Port Configuration dialog box for a fiber port (left) or a copper port (right) appears.



<sup>9</sup> Refer to the *Radiance 100Mbps Single Interface Line Cards Installation and User Guide*, Step 2 "Set the Switches," for additional information.

2. For a fiber port, you can configure the following settings: Administrative Status, Link Loss Return, Loopback, and Far End Fault. For a copper port, you can configure Auto-Negotiation, Administrative Status, and Loopback (locally managed card only).<sup>10</sup>

To change any these port settings, select **Enabled** or **Disabled** from the drop-down list, and then click **Apply**. Click **OK** when the confirmation message appears.


Name	Description
Admin Status	When enabled, the port sends and receives data, including management packets. When disabled, data is neither sent to nor received from the port. However, the port continues to accept, process, and transmit management packets.
Auto-Negotiation	When enabled, the copper port advertises full/half duplex capability. Speed is not auto-negotiated and set to 100Mbps. When disabled, the copper port is set to full duplex.
Far End Fault (FEF)	When FEF is enabled on a remote line card and it loses its receive fiber link, the card sends an unsolicited alarm to the locally managed card. When disabled, the remote card does not send an alarm if it loses its receive fiber link.
Link Loss Return (LLR)	When LLR is enabled, loss of the port's receive link disables its transmit link. When disabled, the port continually transmits an idle signal.
Loopback	When disabled, the port sends data to the receiver. When enabled, the port returns its incoming data back to the sender, while continuing to receive and send management packets. Management packets are not looped back to the sender. Loopback can only be applied to one port at a time because enabling loopback on one port disables the opposite port. Not applicable to the remote copper port.

3. For a singlemode fiber optic port, the input and output laser power levels<sup>11</sup> are displayed in the port configuration dialog box. Click the **Receive Level History** or **Transmit Level History** button or double-click on either of the gauges to view a history of the data over a period of time. (This feature requires the database plugin on your NetBeacon server.)

---

<sup>10</sup> Refer to the *Radiance Access Line Cards ~ Installation and User Guide*, "Software Settings," for additional information.

<sup>11</sup> Refer to the *Radiance Access Line Cards ~ Installation and User Guide*, "Singlemode Fiber Optic Power Monitors," for additional information.



4. To change the maximum time interval shown in the graph, select one of the options from the Time Span drop-down list.
5. Click **Close** to return to the Port Configuration dialog box.

### Displaying Port Statistics

To view the port's RMON statistics, click the **Statistics** tab on the Port Configuration dialog box. The current totals and the deltas are displayed. Deltas are the difference between the current totals and the totals from the previous sampling. The time between samplings typically ranges between 15 and 60 seconds.

Port Configuration - Chassis 4, Slot 1, Port 2

System: 192.168.3.170


Details Statistics Graphs Bandwidth

	Totals	Deltas
Octets	1,655,694	11,996
Packets of All Types	4,193	32
Broadcast Packets	0	0
Multicast Packets	0	0
Packets, 64 Octets	982	4
Packets, 65-127 Octets	386	1
Packets, 128-255 Octets	1,215	15
Packets, 256-511 Octets	818	6
Packets, 512-1023 Octets	175	2
Packets, 1024-1518 Octets	617	4
Error Packets of All Types	0	0
Collisions	0	0
Non-Collisions	0	0
Receive Blocked Octets	0	0
Receive Blocked Packets	0	0
Transmit Blocked Octets	0	0
Transmit Blocked Packets	0	0


OK Apply Cancel

## Viewing Data History Graphs

1. To view pie charts showing the various packet types received, the sizes of those packets, and the types of error packets received, click the **Graphs** tab.



2. Click one of the three History buttons or double-click on any of the pie charts to view a graph displaying those statistics over a period of time.




3. Use the drop-down menu at the bottom of the dialog box to change the time span shown in the graph. For the Packet Size History graph, only the two-hour option is available.

**Important:** Without the database plugin, the maximum time interval shown in the graphs is two hours.

## Provisioning Bandwidth

1. To configure the bandwidth settings for the access line card, select the copper port and click the **Bandwidth** tab. (This tab cannot be selected for a fiber port.)



The top half displays information relating to the incoming bandwidth, and the bottom half displays information relating to the outgoing bandwidth.


The yellow arrowheads point to the highest levels attained in each gauge. Click **Reset Peak Level** to reset the pointer.

Note that the gauges do NOT use the same units. The bandwidth gauges on the left display data in megabits per second (Mbps), while the blocked packet gauges on the right display the percentage of the total packets which were blocked and then dropped. Click the **Statistics** tab to see further details about the information shown in the gauges.

2. To configure the bandwidth settings, do the following:
  - Set the maximum burst size by selecting one of the following options from the Receive or Transmit Burst Length drop-down list:  
  
16, 32, 64, 128, or 256 KB.  
  
This determines the maximum data burst size permitted in that direction. The access line card provides full access to the channel bandwidth until the burst threshold is reached.
  - Set the receive or transmit bandwidth by typing a number between 1 and 100. This sets the maximum amount of data that can be carried over the network in megabits per second (Mbps).
  - Click **Apply**, and then click **OK**.



- Click **History** or double-click on any of the gauges to view a graph displaying the receive or transmit bandwidth usage over a specified period of time.



- To change the maximum time interval shown, select one of the options from the Time Span drop-down menu. Intervals greater than two hours require the database plugin.

### *Configuring the T1/E1 Ports*

To configure a port on the T1/E1 card, do the following:

- Double-click the port to configure in either the chassis view or the Ports folder.
- The Port Configuration dialog box appears. The dialog boxes for a T1 copper port (left) and a T1 fiber port (right) are shown below.

- In the Name textbox, type the *name*<sup>12</sup> to assign to the port.
- To enable or disable the port, select **Enabled** or **Disabled** from the Admin Status drop-down list. Disabling a port has no effect on the incoming data, however, outgoing data from the port will be dropped and AIS will be sent.
- Set Local Loopback according to the following:

For normal operation, set Local Loopback to **Disabled**.

<sup>12</sup> There is a limit of 32 characters for the port name. Do not use the following characters: . ; & = : " < > .

If you want the inbound data on the copper or fiber line to be regenerated and sent back to the sending device, set Local Loopback to **Enabled**. Local loopback can also be enabled on both ports at the same time.

6. Click **Apply**, and then click **OK**.

#### Selecting the Line Code and Line Buildout

1. To set the line code or line buildout on a T1/E1 line card, double-click on its copper port.
2. From the TX Line Code drop-down list, select **B8ZS** or **AMI** for a T1 card, or select **HDB3** or **AMI** for an E1 card.
3. To set the line buildout for a T1 card, select one of the options from the Line Buildout drop-down menu. The line buildout determines the shape of the transmitter's output pulse. Line buildout is not applicable to E1 cards.
4. Click **Apply**, and then click **OK**.

#### Setting BERT 511, Remote Loopback, and Far End Fault

1. To configure BERT 511, remote loopback, or Far End Fault (FEF) for the T1/E1 line card, double-click on its fiber port.
2. Set BERT to **Enabled** if you want the fiber transmitter to send a test sequence on the data channel to the remote unit. The remote unit can be either another line card or a standalone. Set BERT to **Disabled** for normal operation.

**Important:** To test the fiber connection between two T1/E1 line cards, both BERT and Remote Loopback must be enabled individually. The two functions are set automatically through the DIP switch, BR.

3. Set Remote Loopback to **Enabled** to force the data on the fiber line to loop back at the remote end. Only the data bits will be looped, not the management bits. Set Remote Loopback to **Disabled** for normal operation.
4. Set Far End Fault to **Enabled** to send an unsolicited alarm via the fiber management channel if it loses its carrier or receives AIS. Set Far End Fault to **Disabled** if you don't want the remote card to receive an alarm. Far End Fault is enabled by default.
5. Click **Apply**, and then click **OK**.

#### *Configuring the T3/E3 Ports*

To configure a port on the T3/E3 card, do the following:

1. Double-click the port to configure in either the chassis view or the Ports folder.

The Port Configuration dialog box appears. The dialog box for a T3 copper port is shown below.

**Port Configuration - Chassis 1, Slot 16, Port 1**

System: 192.168.3.165

Details | Statistics | Graphs | Bandwidth

Name: Port16\_1

Type: T3

Link Status: No Link

Line Status: Inactive

Oper Status: Enabled

Admin Status: Enabled

Local Loopback: Disabled

Line Buildout: Long

OK Apply Cancel

2. In the Name textbox, type the *name*<sup>13</sup> to assign to the port.
3. To enable or disable the port, select **Enabled** or **Disabled** from the Admin Status drop-down list. Disabling a port stops the flow of data to and from that port. If the copper port is disabled, no signals will be sent from the coaxial transmitter, and an unframed all-ones pattern will be transmitted over the fiber line to the remote line card. If the fiber port is disabled, no signals will be sent from the fiber transmitter, and an unframed all-ones pattern will be passed from the copper port. Once a port is disabled, the only way to enable it again is through software.

**Note:** An all-ones pattern indicates an alarm indication signal (AIS) for the E3 line cards only. For T3 cards, the all-ones pattern is simply transmitted to the remote device; it does NOT indicate AIS.

4. Set Local Loopback to the following:

For normal operation, set Local Loopback to **Disabled**.

The T3/E3 line card provides independent copper and fiber loopback modes. To set either the copper port or the fiber port into loopback, set Local Loopback to **Enabled**. When local loopback is enabled, incoming data is both transmitted to the remote device and returned to the sending device. Copper and fiber loopback cannot be enabled at the same time.

5. Click **Apply**, and then click **OK**.

<sup>13</sup> There is a limit of 32 characters for the port name. Do not use the following characters: . ; & = : " < > .

### Setting the T3 Line Buildout

1. For a T3 line card, an additional option is provided to set the line buildout on the copper port. Line Buildout is not applicable to E3 cards. Double-click on the copper port.
2. Set the Line Buildout to **Short** if your coaxial cable length is less than 255 feet. If the cable is between 255 and 1200 feet, set the Line Buildout to **Long**.
3. Click **Apply**, then click **OK**.

## Appendix A. Persistence Data

---

When a new chassis is initially started, the management module polls all installed modules and saves their part numbers and hardware switch settings.

When a user changes a switch setting via NetBeacon, the software updates the part number, hardware switch settings and new software switch settings.

If the user removes a new module and inserts a new module into its slot, one of the following occurs:

1. If the part number and hardware switch settings match, the software switch settings stay the same.
2. If the part number matches but the hardware switch settings do not, the new hardware switch settings take precedence. All other software settings remain unchanged.
3. If the part number does not match, all hardware switch settings take precedence and the persistence file is updated with the new data.


### The Database Persistence File

The first time a user adds a device for database management, NetBeacon creates a database persistence file. This text file keeps a record of all database management devices and indicates whether or not they are enabled to log data. The file can be modified using any standard text editor.

By default, the database persistence file, `DatabaseControl.txt`, is located in the following directory:

```
NBServer\server\Profiles
```

Below is an example of the contents of a database persistence file.



If you want to edit the file, make sure the following format structure is maintained.

- The first line, which identifies the database version, must not be changed.
- Each device in the database management list must be on a separate line, beginning on the second line. Use only IP addresses to specify devices; DNS names are not permitted.
- If you want the device enabled for logging data, press the TAB key after its IP address and type:

`recording`

The string is case insensitive. If the TAB key is not used between the IP address and "recording," the device will not be enabled for logging data.

## Appendix B. Database Archives

---

NetBeacon maintains a database for each device enabled to log data. The database contains information from the present to a maximum of 28 days back. As new information is added to the database, older data is dropped. To preserve data that is more than 28 days old, NetBeacon provides a mechanism that produces a set of database archives.

### Archive Files

When a device is configured to create database archives, NetBeacon produces four ASCII data files. Each file contains the values for one of four database tables:

- **Chassis statistics**  
Contains a timestamp, management card name, and sensor readings for the temperature and power supply voltages.<sup>14</sup>
- **Access line card statistics**  
Includes a timestamp, card name, and sensor readings for temperature, 1.8-volt power supply, 3.3-volt power supply and 5-volt power supply.
- **Access line card copper port statistics**  
Includes a timestamp, port name and RMON statistics for octets, packets, broadcast, multicast, collisions, non-collision errors, total non-errored packets, unicast, burst receive (rx) speed, blocked rx packets, blocked rx octets, burst transmit (tx) speed, blocked tx packets, and blocked tx octets. NetBeacon does not report a summation of all RMON error fields that overlap.  
  
Total errors = CRC align errors + undersize + oversize  
  
CRC align errors include fragments and jabbers.
- **Access line card fiber port statistics**  
Contains a timestamp, port name and RMON statistics for octets, packets, broadcast, multicast, collisions, non-collisions, total non-errored packets, and unicast. Also includes the laser receive and transmit power levels.

The archive directory also contains the file `TableCreate.sql`. This file contains the Structured Query Language (SQL) statements used to create the tables in the NetBeacon databases. You can use the information in the file to recreate the database on any SQL-compliant database management system.

---

<sup>14</sup> If one of the power supply slots is empty, NetBeacon displays a reading of -2.1E09 volts, which indicates that the power supply is missing.

## Archive File Formats

The archive filenames use the following format:

```
<device>_<start>_<stop>_<table>
```

where <device> is the IP address of the device, <start> and <stop> are the start and end dates of the file's logging period, and <table> is the name of the table where data is contained in the file. The <start> and <stop> components of the filename use the format:

```
YYYYMMDDhhmm
```

where YYYY is the year, MM is the month, DD is the day, hh is the hour and mm is the minute. The following is an example of a database archive filename:

```
100.132.64.104_200305010000_200305292359_MODULESTATS
```

The time span in an archive file begins at 00:00 of the start date and ends at 23:59 of the stop date. For example, if the start date is 2003/05/01 and the stop date is 2003/05/29, the archive files will contain data from May 1, 2003, 00:00 to May 29, 2003, 23:59.

The table format of the database archive files is one line of tab-separated values for each row of data in the table.

## Locating Archive Files

By default, the database archives are located in the following directory:

```
NBeacon/database/archive
```

## Changing Archive File Default Settings

To change the default settings for the database archives, do the following:

1. Open the file `NBdatabase.ini`. Its default directory is:

```
NBServer/server
```

2. To change to directory where the database archive files are located, modify the *archiveLocation* variable.
3. Tabs are used separate values in the database tables. To change the separator, modify the *separatorChar* variable.

Changes take effect upon restarting the NetBeacon server.



## Database Archive Details

This section contains detailed information about the files created by NetBeacon for archiving database information.

### *TableCreate.sql*

The TableCreate.sql file generally contains the following four lines of SQL data:

```
Create table "COPPERPORTSTATS" (zzz_rmon_timestamp LONGINT,  
ENTITY_COLUMN VARCHAR(32), rmon_ether_octets LONGINT, rmon_ether_pkts  
LONGINT, rmon_ether_broadcast_pkts LONGINT, rmon_ether_multicast_pkts  
LONGINT, rmon_ether_collisions LONGINT, rmon_non_collision_error LONGINT,  
rmon_total_no_error LONGINT, rmon_ether_unicast LONGINT,  
esu_burst_rx_speed_oper LONGINT, esu_blocked_rx_packets LONGINT,  
esu_blocked_rx_octets LONGINT, esu_burst_tx_speed_oper LONGINT,  
esu_blocked_tx_packets LONGINT, esu_blocked_tx_octets LONGINT, PRIMARY KEY  
(ZZZ_RMON_TIMESTAMP, ENTITY_COLUMN))
```

```
Create table "FIBERPORTSTATS" (zzz_rmon_timestamp LONGINT, ENTITY_COLUMN  
VARCHAR(32), rmon_ether_octets LONGINT, rmon_ether_pkts LONGINT,  
rmon_ether_broadcast_pkts LONGINT, rmon_ether_multicast_pkts LONGINT,  
rmon_ether_collisions LONGINT, rmon_non_collision_error LONGINT,  
rmon_total_no_error LONGINT, rmon_ether_unicast LONGINT, sensor_current_6  
INTEGER, sensor_current_5 INTEGER, PRIMARY KEY (ZZZ_RMON_TIMESTAMP,  
ENTITY_COLUMN))
```

```
Create table "MODULESTATS" (THE_TIMESTAMP LONGINT, ENTITY_COLUMN  
VARCHAR(32), sensor_type_3 INTEGER, sensor_type_8 INTEGER, sensor_type_9  
INTEGER, sensor_type_10, sensor_type_16 INTEGER, PRIMARY KEY  
(THE_TIMESTAMP, ENTITY_COLUMN))
```

```
Create table "CHASSISSTATS" (THE_TIMESTAMP LONGINT, ENTITY_COLUMN  
VARCHAR(32), sensor_type_3 INTEGER, A_sensor_type_10 INTEGER,  
B_sensor_type_10 INTEGER, PRIMARY KEY (THE_TIMESTAMP, ENTITY_COLUMN))
```

Each of the SQL command lines above, when executed in an SQL-compliant database, creates a table with appropriately named columns. Using SQL INSERT, the delimited data files that were created through the NetBeacon Database Archive mechanism can now be imported. The files are located in `NBServer/server/archive`. Note that there are 1, 7, and 28 day tables for each primary category (Copper Ports, Fiber Ports, Modules, and Chassis).

Associations between the database archive and the tables are listed below.

### ***COPPERPORTSTATS***

<b>Archive Database Name</b>	<b>Definition</b>
zzz_rmon_timestamp	UTC time in milliseconds
ENTITY_COLUMN	Port number/name relative to the chassis/ module
rmon_ether_octets	RMON Ethernet statistics for octets
rmon_ether_pkts	RMON Ethernet statistics for packets
rmon_ether_broadcast_pkts	RMON Ethernet statistics for broadcast packets
rmon_ether_multicast_pkts	RMON Ethernet statistics for multicast packets
rmon_ether_collisions	RMON Ethernet statistics for collisions
rmon_non_collision_error	RMON Ethernet statistics for non-collision errors
rmon_total_no_error	RMON Ethernet statistics for total non-erred packets
rmon_ether_unicast	RMON Ethernet statistics for unicast packets
esu_burst_rx_speed_oper	Settings for burst receive (RX) speed
esu_blocked_rx_packets	Statistics for blocked RX packets
esu_blocked_rx_octets	Statistics for blocked RX octets
esu_burst_tx_speed_oper	Settings for burst transmit (TX) speed
esu_blocked_tx_packets	Statistics for blocked TX packets
esu_blocked_tx_octets	Statistics for blocked TX octets

### ***FIBERPORTSTATS***

<b>Archive Database Name</b>	<b>Definition</b>
zzz_rmon_timestamp	UTC time in milliseconds
ENTITY_COLUMN	Port number/name relative to the chassis/ module
rmon_ether_octets	RMON Ethernet statistics for octets
rmon_ether_pkts	RMON Ethernet statistics for packets
rmon_ether_broadcast_pkts	RMON Ethernet statistics for broadcast packets

Archive Database Name	Definition
rmon_ether_multicast_pkts	RMON Ethernet statistics for multicast packets
rmon_ether_collisions	RMON Ethernet statistics for collisions
rmon_non_collision_error	RMON Ethernet statistics for non-collision errors
rmon_total_no_error	RMON Ethernet statistics for total non-erred packets
rmon_ether_unicast	RMON Ethernet statistics for unicast packets
sensor_current_6	Optical laser receive power level in dbm
sensor_current_5	Optical laser transmit power level in dbm

### **MODULESTATS**

Archive Database Name	Definition
THE_TIMESTAMP	UTC time in milliseconds
ENTITY_COLUMN	Module number/name relative to the chassis
sensor_type_3	Sensor readings for temperature
sensor_type_8	1.8-volt power supply voltage readings
sensor_type_9	3.3-volt power supply voltage readings
sensor_type_10	5-volt power supply voltage readings
sensor_type_16	1.5-volt power supply voltage readings

### **CHASSISSTATS**

Archive Database Name	Definition
THE_TIMESTAMP	UTC time in milliseconds
ENTITY_COLUMN	Management card number/name in the chassis
sensor_type_3	Chassis temperature in Celsius
A_sensor_type_10	Chassis power supply voltage readings
B_sensor_type_10	Chassis power supply voltage readings

## UTC Time Conversion

Note that the first column item, "timestamp," represents UTC time as represented in milliseconds from midnight January 1, 1970.

Some algorithms that can be used as a guide for converting the representation of the UTC time in the database archive into a more readable format is provided in examples at <http://www.arm.gov/docs/data/time.html>. Other examples can be found at <http://archive.devx.com/premier/mgznarch/vbpj/1999/08aug99/mt0899.pdf>.

### *Conversion Examples and Hints*

#### **Perl Example**

`gmtime()` command:

```
% perl -e 'print scalar gmtime(992794875), "\n"'
```

returns:

```
Sun Jun 17 16:21:15 2001
```

The C (and Fortran) function that does much the same thing is called `ctime()`.

#### **C Example**

For more complicated manipulations, you can write a program in C, Fortran, or Perl using the `gmtime()` functions; consult that function's documentation in those languages for more details. The following C program returns the year and day of the year (i.e., days since Dec. 31 of the previous year, or the "julian day"), given an epoch time:

```
#include "time.h"

/* program time_jday */

main(){

    struct tm *t;

    long epoch=992794875;

    t = gmtime ((time_t *)&epoch);

    printf("The year is: %d\n", t->tm_year + 1900);

    printf("The julian day is: %d\n", t->tm_yday + 1);

}
```

returns:

```
% time_jday  
  
The year is: 2001  
  
The julian day is: 168
```

## Graphing Granularity

Note that the algorithms for the 1-day, 7-day, and 28-day graphs utilize the stored database values differently. The database values are stored every 15 minutes.

- **Database: Max 1 Day** - Graphs data in a window that tracks at 15-minute intervals. Utilizes and displays all 15-minute data points.
- **Database: Max 7 Days** - Graphs data in a window that tracks at 30-minute intervals. Averages data points to produce 30-minute data points.
- **Database: Max 28 Days** - Graphs data in a window that tracks at 60-minute intervals. Averages data points to produce 60-minute data points.



## Appendix C. Download Error Messages

While attempting to download new software, you may receive an error message. The following table lists some common errors with solutions to help you correct them. Contact Metrobility's technical support if you are unable to resolve a problem.

Error	Solution
Alert: FTP failure during transfer	Do not ignore this message. Try downloading the software again, or manually reload the files through your local console.
Alert: telnet copyboot failed	Manually issue a copyboot command via telnet or console, or contact Metrobility technical support.
Copyboot failure	Contact Metrobility technical support.
Device not available	Check your network connections.
Failed to initiate copyboot	Manually issue a copyboot command via telnet or console.
Failed to reset	Select <b>Reset Chassis</b> in the Stack folder.
FTP failed – couldn't establish connection	Check your network connections.
FTP failed – unknown host	Check your network connections.
FTP failed to initiate copyboot	Start copyboot manually according to directions in the <i>Command Line Interface Reference Guide</i> .
FTP login failure – user known; login failed or login incorrect.	Enter the user name and password you have set for the device.
Skipped – complete update required	Choose <b>Complete update</b> from the Embedded Software Download dialog box.





## Appendix D. HP NNM Customization

---

### HP NNM Installation

1. Install HP Network Node Manager Release 6.2.
2. Go to the HP support site:

<http://support.openview.hp.com/cpe/patches/nnm/nnm.jsp>

Here you can get NNM Release 6.2 software patches for HP-UX, Solaris, and Windows 2000/NT.

3. Choose your OS and scroll to the selection, "Symptoms: Cumulative Consolidated Patch." It is **PHSS\_25743** for HP-UX, **PSOV\_03061** for Solaris, and **NNM\_00831** for NT/2000.
4. Download the appropriate patch and install it. Once this is done, proceed to Enable Metrobility Customization.

### Enable Metrobility Customization

To enable a customized view of Metrobility's product line through HP Network Node Manager, you must create new Alarm Categories and customize the results of the MIB loads for Metrobility's products. To do this, use the scripts provided in the installation directory, `Utilities\NNM\` Configuration. The directory contains the following files:

- `category.txt` (Adds the new "Metrobility Alarm" category)
- `enable_events.cmd` (For Windows environments)
- `enable_events.sh` (For UNIX environments)
- `events_on.txt` (Enables events to be captured in the new "Metrobility Alarm" category)

The contents of the `category.txt` file is as follows:

```
CATEGORY 2 "Metrobility Alarms" "Metrobility Alarms"
```

The contents of the `events_on.txt` file is a duplicate of the information that is contained in the `trapd.conf` file for Metrobility-specific devices with the exception that each event is reclassified and each format for display is modified as follows:

```
EVENT <Metrobility_Trap> <address> "Metrobility Alarms" Normal
```

```
FORMAT Metrobility <Metrobility_Action> - <name>:<variable> ...
```

Where <Metrobility\_Trap> specifies the trap itself such as "lancastPhysicalEntityRemoveTrap" and <Metrobility\_Action> specifies the Event Action such as "Entity Remove". <Name> indicates a class of description for the user, and <variable> gives more information about the entity alarm and there may be a sequence of these as necessary.

You should customize these settings as needed and then run the appropriate enable script for the environment in which NNM is running, either Windows or UNIX, after the Metrobility MIBs have been loaded. To make the file executable on UNIX, you may have to run the following command:

```
chmod +x enable_events.sh
```

## Details of trapd.conf Changes

The following examples identify the default original value of trapd.conf after loading our MIBs and the changes that will occur to the trapd.conf after the script automation occurs.

After MIB Load:

```
EVENT lancastPhysicalEntityInsertTrap .1.3.6.1.4.1.2745.11.3.2.0.1  
"LOGONLY" Normal
```

```
FORMAT NO FORMAT DEFINED
```

After Script Change:

```
EVENT lancastPhysicalEntityInsertTrap .1.3.6.1.4.1.2745.11.3.2.0.1  
"Metrobility Alarms" Normal
```

```
FORMAT Metrobility Entity Insert - PhysicalClass:$3 PhysicalName:$4  
PhysicalModelName:$5
```

—

After MIB Load:

```
EVENT lancastPhysicalEntityRemoveTrap .1.3.6.1.4.1.2745.11.3.2.0.2  
"LOGONLY" Normal
```

```
FORMAT NO FORMAT DEFINED
```

After Script Change:

```
EVENT lancastPhysicalEntityRemoveTrap .1.3.6.1.4.1.2745.11.3.2.0.2  
"Metrobility Alarms" Normal
```

```
FORMAT Metrobility Entity Remove - PhysicalClass:$3 PhysicalName:$4  
PhysicalModelName:$5
```

—

#### After MIB Load:

```
EVENT lancastPhysicalEntityResetTrap .1.3.6.1.4.1.2745.11.3.2.0.3 "LOGONLY"  
Normal
```

```
FORMAT NO FORMAT DEFINED
```

#### After Script Change:

```
EVENT lancastPhysicalEntityResetTrap .1.3.6.1.4.1.2745.11.3.2.0.3  
"Metrobility Alarms" Normal
```

```
FORMAT Metrobility Entity Reset - PhysicalLastResetReason:$3  
SpecificType:$4 PhysicalClass:$5
```

—

#### After MIB Load:

```
EVENT lancastPowerSupplyStatusChangeTrap .1.3.6.1.4.1.2745.11.3.2.0.4  
"LOGONLY" Normal
```

```
FORMAT NO FORMAT DEFINED
```

#### After Script Change:

```
EVENT lancastPowerSupplyStatusChangeTrap .1.3.6.1.4.1.2745.11.3.2.0.4  
"Metrobility Alarms" Normal
```

```
FORMAT Metrobility Power Supply Status Change - PowerSupplyStatus:$3  
PhysicalClass:$4 PhysicalName:$5
```

—

#### After MIB Load:

```
EVENT lancastEnetPortLinkStatusChangeTrap .1.3.6.1.4.1.2745.11.3.2.0.5  
"LOGONLY" Normal
```

```
FORMAT NO FORMAT DEFINED
```

#### After Script Change:

```
EVENT lancastEnetPortLinkStatusChangeTrap .1.3.6.1.4.1.2745.11.3.2.0.5  
"Metrobility Alarms" Normal
```

```
FORMAT Metrobility Enet Port Link Status Change - PortLinkStatus:$2  
PhysicalName:$3 Alias:$4
```

—

#### After MIB Load:

```
EVENT lancastSonetPortLinkStatusChangeTrap .1.3.6.1.4.1.2745.11.3.2.0.6
"LOGONLY" Normal
```

```
FORMAT NO FORMAT DEFINED
```

#### After Script Change:

```
EVENT lancastSonetPortLinkStatusChangeTrap .1.3.6.1.4.1.2745.11.3.2.0.6
"Metrobility Alarms" Normal
```

```
FORMAT Metrobility Sonet Port Link Status Change - PortLinkStatus:$2
PhysicalName:$3 Alias:$4
```

—

#### After MIB Load:

```
EVENT lancastSensorThresholdTrap .1.3.6.1.4.1.2745.11.3.2.0.7 "LOGONLY"
Normal
```

```
FORMAT NO FORMAT DEFINED
```

#### After Script Change:

```
EVENT lancastSensorThresholdTrap .1.3.6.1.4.1.2745.11.3.2.0.7 "Metrobility
Alarms" Normal
```

```
FORMAT Metrobility Sensor Threshold - SensorCurrent:$3 PhysicalName:$4
ModelName:$5
```

—

#### After MIB Load:

```
EVENT lancastRtwSwitchOverTrap .1.3.6.1.4.1.2745.11.3.2.0.8 "LOGONLY"
Normal
```

```
FORMAT NO FORMAT DEFINED
```

#### After Script Change:

```
EVENT lancastRtwSwitchOverTrap .1.3.6.1.4.1.2745.11.3.2.0.8 "Metrobility
Alarms" Normal
```

```
FORMAT Metrobility Rtw SwitchOver - PhysicalName:$3 ModelName:$4
```

—

#### After MIB Load:

```
EVENT lancastEnetPortEsuFarEndFaultAlarmTrap .1.3.6.1.4.1.2745.11.3.2.0.9
"LOGONLY" Normal
```

```
FORMAT NO FORMAT DEFINED
```

#### After Script Change:

```
EVENT lancastEnetPortEsuFarEndFaultAlarmTrap .1.3.6.1.4.1.2745.11.3.2.0.9  
"Metrobility Alarms" Normal
```

```
FORMAT Metrobility Enet Port Esu FarEnd Fault Alarm - PhysicalName:$3  
Alias:$4
```

—

#### After MIB Load:

```
EVENT lancastEnetPortSpeedChangeTrap .1.3.6.1.4.1.2745.11.3.2.0.10  
"LOGONLY" Normal
```

```
FORMAT NO FORMAT DEFINED
```

#### After Script Change:

```
EVENT lancastEnetPortSpeedChangeTrap .1.3.6.1.4.1.2745.11.3.2.0.10  
"Metrobility Alarms" Normal
```

```
FORMAT Metrobility Enet Port Speed Change - PhysicalName:$3 Alias:$4
```

—

#### After MIB Load:

```
EVENT lancastTdmPortLinkStatusChangeTrap .1.3.6.1.4.1.2745.11.3.2.0.11  
"LOGONLY" Normal
```

```
FORMAT NO FORMAT DEFINED
```

#### After Script Change:

```
EVENT lancastTdmPortLinkStatusChangeTrap .1.3.6.1.4.1.2745.11.3.2.0.11  
"Metrobility Alarms" Normal
```

```
FORMAT Metrobility Tdm Port Link Status Change - PortLinkStatus:$2  
PhysicalName:$3 Alias:$4
```

—

#### After MIB Load:

```
EVENT lancastTdmPortFarEndFaultAlarmTrap .1.3.6.1.4.1.2745.11.3.2.0.12  
"LOGONLY" Normal
```

```
FORMAT NO FORMAT DEFINED
```

#### After Script Change:

```
EVENT lancastTdmPortFarEndFaultAlarmTrap .1.3.6.1.4.1.2745.11.3.2.0.12  
"Metrobility Alarms" Normal
```

FORMAT Metrobility Tdm Port Far End Fault Alarm - PhysicalName:\$3 Alias:\$4

## Appendix E. Discontinued Product Support


Metrobility aims to offer high quality software support to our customers. In order to do this, it may be necessary to discontinue products with a diminished market demand, so that available resources can be used to develop newer technology desired by our customers.

This version of NetBeacon provides only basic support for discontinued products, such as the Lancast 10Mbps Fixed Port Chassis. Metrobility does not conduct extensive testing on discontinued products and full compatibility with the latest software is not assured.

### Managed Fixed Port Chassis



If you are managing a Lancast fixed port chassis, above, the view in the NetBeacon Devices List in the lower left frame will be as follows:




Converters are the replaceable line cards (modules) installed into a chassis. On a fixed port chassis, they are the factory-installed boards.

The Module Information folder displays information about the replaceable cards installed in the chassis. For a fixed port chassis, the folder displays information about the management module and a module representing all of the media converters in that chassis. The management module is located in slot 1 of a fixed port chassis. Module2-x represents each individual media converter, where x is the converter number.

To configure Link Loss Carry Forward on a converter, right-click on the port and choose **Converter Configuration**, as shown below.



To configure Link Loss Return on a fiber port, double-click on the port to configure. Alternatively, from the rear view of a fixed port chassis with Telco connectors, right-click on a connector and select the port from the pop-up menu as shown in the following illustration.



## Persistence Data for a Fixed Port Chassis

When a management module is installed in a fixed port chassis, pushing any LLCF/LLR switch takes effect immediately. Persistence works as outlined below.

1. If the switch setting matches the setting in the persistence data file, the software setting will be enforced, and the persistence data file will be unaffected.
2. If the switch settings do not match because a change was made, the new hardware switch setting takes precedence. All other software settings will stay the same.



## Appendix F. NetBeacon Warranty Statement

---

Metrobility Optical Systems, Inc. warrants that a) the SOFTWARE PRODUCT will perform substantially in accordance with the accompanying written materials for a period of ninety (90) days from the date of receipt, and b) any Support Services provided by Metrobility shall be substantially as described in applicable written materials provided to you by Metrobility, and Metrobility support engineers will make commercially reasonable efforts to solve any problem issues. Some states and jurisdictions do not allow limitations on duration of an implied warranty, so the above limitation may not apply to you. To the extent allowed by applicable law, implied warranties on the SOFTWARE PRODUCT, if any, are limited to ninety (90) days.

SUPPORTED VERSIONS. Metrobility supports only the current released version and the most recent previous minor version of the SOFTWARE PRODUCT.

CUSTOMER REMEDIES. Metrobility and its suppliers' entire liability and your exclusive remedy shall be repair or replacement of the SOFTWARE PRODUCT that does not meet Metrobility's limited warranty and which is returned to Metrobility with proof of purchase. This limited warranty is void if failure of the SOFTWARE PRODUCT has resulted from accident, abuse, or misapplication. Any replacement SOFTWARE PRODUCT will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer. Outside the United States, neither these remedies nor any product support services offered by Metrobility are available without proof of purchase from an authorized international source.

NO OTHER WARRANTIES. To the maximum extent permitted by applicable law, Metrobility and its suppliers disclaim all other warranties and conditions, either express or implied, including, but not limited to, implied warranties of merchantability, fitness for a particular purpose, title, and non-failure to provide support services. This limited warranty gives you specific legal rights. You may have others, which vary from state/jurisdiction to state/jurisdiction.

LIMITATION OF LIABILITY. To the maximum extent permitted by applicable law, in no event shall Metrobility or its suppliers be liable for any special, incidental, indirect, or consequential damages whatsoever (including, without limitations, damages for loss of business profits, business interruption, loss of business information, or any other pecuniary loss) arising out of the use of or inability to use the SOFTWARE PRODUCT or the provision of failure to provide support services, even if Metrobility has been advised of the possibility of such damage. In any case, Metrobility's entire liability shall be limited to the amount actually paid by you for the SOFTWARE PRODUCT. Metrobility's entire liability regarding support services shall be governed by the terms of that agreement. Because some states and jurisdictions do not allow the exclusion or limitation of liability, the above limitation may not apply to you.

## **Software Maintenance and Support Agreement**

Metrobility Optical Systems, Inc. offers an optional one-year software maintenance and support plan. The plan includes free electronic mail and telephone technical support, along with all minor and maintenance releases for this version of the software for a period of one year.

To purchase the agreement, contact your reseller or the Metrobility Sales Department.

## **Appendix G. Product Safety and Compliance Statements**

---

The Lanecast Intelligent 7500 Chassis and Radiance service platforms comply with the following standards and protocols:

- Internet Protocol (IP), RFC 791
- Address Resolution Protocol (ARP), RFC 826
- Simple Network Management Protocol (SNMP), RFC 1157 and 1442
- Management Information Base for Network Management of TCP/IP-based Internets (MIB-II), RFC 1213
- Boot Protocol (BOOTP)
- Simple Mail Transfer Protocol (SMTP), RFC 821
- File Transfer Protocol (FTP)
- Reverse Address Resolution Protocol (RARP)
- Remote Network Monitoring Management Information Base, RFC 2819
- Entity MIB (Version 2), RFC 2737

This product shall be handled, stored and disposed of in accordance with all governing and applicable safety and environmental regulatory requirements.


#### **Product Manuals**

The most recent version of this manual is available online at  
<http://www.metrobility.com/support/manuals.htm>

To obtain additional copies of this manual, contact your reseller, or call  
1.877.526.2278 or 1.603.880.1833

#### **Product Registration**

To register your product, go to  
<http://www.metrobility.com/support/registration.asp>



**25 Manchester Street, Merrimack, NH 03054 USA**  
**1.603.880.1833 FAX: 1.603.594.2887**  
[www.metrobility.com](http://www.metrobility.com)

5660-NETBEACON  
6/03

---